Mandis shop

WL-61

| Original | | Substituto | |
|---|---|---|---|
| START /STOP | Start/Stop | | Power |
| W | Zoom W | CH PAGE + | CH+ / Page+ |
| T | Zoom T | CH PAGE − | CH- / Page- |
| | Left | | Left |
| | Up | | Up |
| | Right | | Right |
| | Down | | Down |
| PLAY | Play | SLOW ▶ | Play / Slow |
| STOP | Stop | HOLD ■ | Stop / Hold |
| EXECUTE | Execute | OK | OK |
| REW/ | <</Rew | TUNE- ◀◀ | << / Tune- |
| FF/ | >>/FF | TUNE+ ▶▶ | >> / Tune+ |
| COUNTER RESET | Counter Reset | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| PAUSE | Pause | STEP-FREEZE ⏸ | Pause / Step / Freeze |
| ON SCREEN | On Screen | MEDIA DISPLAY | Display / Media |
| TAPE RETURN | Tape Return | RETURN BACK | Back / Return |

https://controleremoto.pt/pt/Canon/1067054-79814-comando-de-substituicao-para-Canon-WL-61.html