Mandis shop

10201

Original		Substituto	
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Zoom+	SIZE ZOOM	Zoom / Size
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
	Sleep	TIMER SLEEP	Sleep / Timer
ROTATE	Rotate	RETURN BACK	Back / Return
COPY/DEL	Copy/Del	LIST SMART	Smart / List
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
SLIDE SHOW	Slide Show	PROGRAM TV/ RADIO	TV/Radio /
STOP	Stop	HOLD	Stop / Hold
	Down		Down

Original	Substituto

https://controleremoto.pt/pt/Telefunken/1067339-93160-comando-de-substituicao-para-Telefunken-10201.html