Mandis shop

LSSQ0336

Original	Substituto	Original	Substituto
Start/Stop	Power	Zoom W	Down
Play	Play / Slow	Vol +	Vol +
Pause/Item	Pause / Step / Freeze	Counter	Smart / List
Stop/Set	Stop / Hold	Vol -	Vol -
Rec	Rec / Rec Mode	OSD	Display / Media
<<	<< / Tune-		
>>	>> / Tune+		
I<< Index	I<< / Preset-		
Index >>I	>>I / Preset+		
A DUB	Audio / Lang I/II		
Photo Shot	Picture / Format		
Date/Time	Sleep / Timer		
Menu	Menu / Home		
Zoom T	Up		
◁ Still Adv	Left		
Still Adv ▷	Right		
Reset	Exit / Cancel / Clear		

https://ordered.pt/p/Panasonic/1676-145-mandis-substituto-para-Panasonic-LSSQ0336.htm