Original		Substituto	
	Power		Power
INFO	Info	ANGLE INFO	Info / Angle
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
ABC 2	2	DVD 2	2
DEF 3	3	CD-STB 3	3
GHI 4	4	VIDEO 4	4
JKL 5	5	TAPE 5	5
MNO 6	6	TUNER 6	6
PQRS 7	7	AUX-HDD 7	7
TUV 8	8	USB 8	8
WXYZ 9	9	BLUETOOTH 9	9
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
0	0	HDMI-SAT 0	0
	Audio I-II	LANG I/II AUDIO	Audio / Lang I/II
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Original		Substituto	
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Down		Down
CH+	CH+	CH PAGE +	CH+ / Page+
		MEDIA DISPLAY	Display / Media
VOL+	Vol +	VOL +	Vol +
CH-	CH-	CH PAGE −	CH- / Page-
LIST	List / Repeat	LIST SMART	Smart / List
LIST	List / Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
VOL-	Vol -	VOL −	Vol -
♥	♥ / Title	TITLE SOUND	Sound / Title
SLEEP	Sleep / Menu	TIMER SLEEP	Sleep / Timer
SLEEP	Sleep / Menu	TOP MENU D.MENU	D. Menu / Top
EPG	EPG / Setup	-/-- GUIDE EPG	Guide / EPG / -/--
EPG	EPG / Setup	OPT-TOOLS SETUP	Setup / OPT / Tools

Original	Substituto
Recall	RETURN BACK — Back / Return
♥ / Title	PC FAV MARKER — Fav / Marker / PC
Red / <<	NETFLIX SEARCH — Red / Netflix / Search
Red / <<	TUNE- — << / Tune-
Green / >>	APP REPEAT — Green / APP / Repeat
Green / >>	TUNE+ — >> / Tune+
Yellow / I<<	YouTube REPEAT A-B — Yellow / YouTube / Repeat
Yellow / I<<	PRESET- — I<< / Preset-
Blue / >>I	Prime Video RANDOM — Blue / Prime Video / Random
Blue / >>I	PRESET+ — >>I / Preset+
Text / Play/Paus	GOTO TEXT — Text / Goto
Text / Play/Paus	SLOW — Play / Slow
Text / Play/Paus	STEP-FREEZE — Pause / Step / Freeze
STILL Still / Stop / T Hold	HOLD — Stop / Hold
RADIO E/W E/W / Radio / Open/Close	SHIFT + PROGRAM TV/RADIO — Shift + TV/Radio / Program
RADIO E/W E/W / Radio / Open/Close	SURROUND — Eject / Surround
Aspect / Text Si	SIZE ZOOM — Zoom / Size

Original	Substituto
Angle / Text	SHIFT + ANGLE INFO — Shift + Info / Angle
Subtitle / Text Subcode	EQ SUBTITLE — Subtitle / EQ
Prog	PROGRAM TV/RADIO — TV/Radio /
DVD / SD / USB	SHIFT + USB 8 — Shift + 8
DVD / SD / USB	SHIFT + DVD 2 — Shift + 2

Original		Substituto	
	Power		Power
INFO	Info	ANGLE INFO	Info / Angle
	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
ABC 2	2	DVD 2	2
DEF 3	3	CD - STB 3	3
GHI 4	4	VIDEO 4	4
JKL 5	5	TAPE 5	5
MNO 6	6	TUNER 6	6
PQRS 7	7	AUX - HDD 7	7
TUV 8	8	USB 8	8
WXYZ 9	9	BLUETOOTH 9	9
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
0	0	HDMI - SAT 0	0
	Audio I/II	LANG I/II AUDIO	Audio / Lang I/II
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear

Original		Substituto	
	Up		Up
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
	Down		Down
CH+	CH +	CH PAGE +	CH+ / Page+
		MEDIA DISPLAY	Display / Media
VOL+	Vol +	VOL +	Vol +
CH-	CH -	CH PAGE −	CH- / Page-
REPEAT LIST	List / Repeat	LIST SMART	Smart / List
REPEAT LIST	List / Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
VOL-	Vol -	VOL −	Vol -
TITLE ♥	♥ / Title	PC FAV MARKER	Fav / Marker / PC
TITLE ♥	♥ / Title	TITLE SOUND	Sound / Title
MENU SLEEP	Sleep / Menu	TIMER SLEEP	Sleep / Timer
MENU SLEEP	Sleep / Menu	TOP MENU D.MENU	D. Menu / Top
REPEAT EPG	EPG / Setup	-/-- GUIDE EPG	Guide / EPG / -/--

Original	Substituto
EPG / Setup	Setup / OPT /
Recall	Back / Return
Red / <<	Red / Netflix / Search
Red / <<	<< / Tune-
Green / >>	Green / APP / Repeat
Green / >>	>> / Tune+
Yellow / I<<	Yellow / YouTube / Repeat
Yellow / I<<	I<< / Preset-
Blue / >>I	Blue / Prime Video / Random
Blue / >>I	>>I / Preset+
Text / Play/Paus	Play / Slow
Text / Play/Paus	Pause / Step / Freeze
Text / Play/Paus	Text / Goto
Still / Stop / T Hold	Stop / Hold
E/W / Radio / Open/Close	Shift + Eject / Surround
E/W / Radio / Open/Close	Eject / Surround
Aspect / Text Si	Zoom / Size

Original	Substituto
Angle / Text	Shift + Info / Angle
Subtitle / Text Subcode	Subtitle / EQ
Prog	TV/Radio /
DVD / SD / USB	Shift + 8
DVD / SD / USB	Shift + 2