| Original | | Substituto | |
|---|---|---|---|
| | Power | | Power |
| | HDMI / Control | HOME SMART | Smart |
| | Rec | REC MODE | Rec |
| | Stop | | Stop |
| | Play | PLAY MODE | Play |
| | Pause | | Pause |
| | << | | << |
| | >> | | >> |
| | I << | | I << |
| | >>I | | >>I |
| ZOOM | Red/ Zoom/ ↑↓ | A | Red |
| REPEAT | Green/ Repeat / ↓ | B | Green |
| ROOT | Yellow/ Root | C | Yellow |
| TITLE | Blue/ Title | D | Blue |
| SCREEN | Screen | PICTURE FORMAT | Format |
| LANG | Lang | SOUND DUAL | Dual |
| SUBTITLE | Subtitle | AD SUBT | Subt |

| Original | | Substituto | |
|---|---|---|---|
| | Internet / PIP | APP MEDIA | Media |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| TEXT | Text | REPEAT TEXT | Text |
| INFO | Info | DISPLAY INFO | Info |
| SOURCE | Source | TIMER AV | AV |
| OK | OK | OK | Ok |
| | Up | | Up |
| | Down | | Down |

| Original | Substituto | Original | Substituto |
|---|---|---|---|
| Right | Right | | |
| Left | Left | | |
| P+ | Ch + | | |
| P- | Ch - | | |
| Vol + | Vol + | | |
| Vol - | Vol - | | |
| Menu | Menu | | |
| Mute | Mute | | |
| Return | Back | | |
| Swap | Pre Ch | | |
| FAV | Shift + Pre Ch | | |
| EPG | Guide | | |
| Sleep | Sleep | | |
| Search Mode | Shift + AV | | |
| Ball / Angle | Options | | |
| Display | Shift + Info | | |
| Presets | TV/R | | |