Mandis shop

T4

Original		Substituto	
	Power		Power
AUX	AUX	A	Red
DIGITAL	Digital	D	Blue
	Bluetooth	B	Green
	Play	PLAY MODE	Play
	Pause		Pause
	>>I		>>I
	I<<		I<<
	Vol+	VOL +	Vol +
	Vol-	VOL −	Vol -

Original	Substituto

https://controleremoto.pt/pt/CREATIVE/1062147-89784-comando-de-substituicao-para-CREATIVE-T4.html