| Original | Substituto | Original | Substituto |
|---|---|---|---|
| Power | Power | P+ | CH+ / Page+ |
| 1 | 1 | Up | Up |
| 2 | 2 | Vol - | Vol - |
| 3 | 3 | Left | Left |
| 4 | 4 | OK | OK |
| 5 | 5 | Vol + | Vol + |
| 6 | 6 | Right | Right |
| 7 | 7 | TXT/Menu | Menu / Home |
| 8 | 8 | TXT/Menu | Text / Goto |
| 9 | 9 | P- | CH- / Page- |
| 0 | 0 | Down | Down |
| ? | Smart / List | TV-G/Top Menu | D.Menu / Top |
| [ <>]/[ . . . ] | Setup / OPT / | Red/Picture/Re | Red / Netflix / Search |
| AV | AV / Input / RDS | Red/Picture/Re | Rec / Rec Mode |
| Mute | Mute / Dimmer | Green/Timer/Play | Green / APP / Repeat |
| i | Info / Angle | Green/Timer/Play | Sleep / Timer |
| PIP/Recall | Back / Return | Green/Timer/Play | Play / Slow |

| Original | Substituto | Original | Substituto |
|---|---|---|---|
| Yellow/ Pause | Yellow / YouTube / Repeat | | |
| Yellow/ Pause | Pause / Step / Freeze | | |
| Blue/ Audio/ Stop | Audio / Lang I/II | | |
| Blue/ Audio/ Stop | Blue / Prime Video / Random | | |
| Blue/ Audio/ Stop | Stop / Hold | | |
| I◁/ Scan | I<< / Preset- | | |
| ▷I / PAP | >>I / Preset+ | | |
| <◁/ S | << / Tune- | | |
| <◁/ S | Sound / Title | | |
| >▷/ P | >> / Tune+ | | |
| >▷/ P | Picture / Format | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Substituto | |
|---|---|---|---|
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | 0 | | 0 |
| | ? | | Smart / List |
| | [ <>]/[ . . . ] | | Subtitle / EQ |
| | AV | | AV / Input / RDS |
| | Mute | | Mute / Dimmer |
| | i | | Info / Angle |
| | PIP/Recall | | Back / Return |

| Original | | Substituto | |
|---|---|---|---|
| | P+ | | CH+ / Page+ |
| | Up | | Up |
| | Vol - | | Vol - |
| | Left | | Left |
| | OK | | OK |
| | Vol + | | Vol + |
| | Right | | Right |
| | TXT/Menu | | Menu / Home |
| | P- | | CH- / Page- |
| | Down | | Down |
| | TV-G/Top Menu | | D.Menu / Top |
| | Red/Picture/Rec | | Rec / Rec Mode |
| | Red/Picture/Rec | | Red / Netflix / Search |
| | Green/Timer/Play | | Sleep / Timer |
| | Green/Timer/Play | | Play / Slow |
| | Green/Timer/Play | | Green / APP / Repeat |
| | Yellow/Pause | | Yellow / YouTube / Repeat |

| Original | Substituto | Original | Substituto |
|---|---|---|---|
| Yellow/Pause | STEP-FREEZE Pause / Step / Freeze | | |
| Blue/Audio/Stop | Prime Video RANDOM Blue / Prime Video / Random | | |
| Blue/Audio/Stop | LANG I/II AUDIO Audio / Lang I/II | | |
| Blue/Audio/Stop | HOLD Stop / Hold | | |
| I◁/Scan | PRESET- I<< / Preset- | | |
| ▷I/PAP | PRESET+ >>I / Preset+ | | |
| <<◁/S | TUNE- << / Tune- | | |
| >>▷/P | TUNE+ >> / Tune+ | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Substituto | |
|---|---|---|---|
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | 0 | | 0 |
| | ? | | Smart / List |
| | [ <>]/[ . . . ] | | Subtitle / EQ |
| | AV | | AV / Input / RDS |
| | Mute | | Mute / Dimmer |
| | i | | Info / Angle |
| | PIP / Recall | | Back / Return |

| Original | | Substituto | |
|---|---|---|---|
| | P+ | | CH+ / Page+ |
| | Up | | Up |
| | Vol - | | Vol - |
| | Left | | Left |
| | OK | | OK |
| | Vol + | | Vol + |
| | Right | | Right |
| | TXT/Menu | | Menu / Home |
| | P- | | CH- / Page- |
| | Down | | Down |
| | TV-G/Top Menu | | D.Menu / Top |
| | Red/Picture/Re | | Red / Netflix / Search |
| | Red/Picture/Re | | Rec / Rec Mode |
| | Green/Timer/Play | | Sleep / Timer |
| | Green/Timer/Play | | Green / APP / Repeat |
| | Green/Timer/Play | | Play / Slow |
| | Yellow/Pause | | Yellow / YouTube / Repeat |

| Original | Substituto | Original | Substituto |
|---|---|---|---|
| Yellow/Pause | STEP-FREEZE / Pause / Step / Freeze | | |
| Blue/Audio/Stop | Prime Video / RANDOM / Blue / Prime Video / Random | | |
| Blue/Audio/Stop | LANG I/II / AUDIO / Audio / Lang I/II | | |
| Blue/Audio/Stop | HOLD / Stop / Hold | | |
| I◁/Scan | PRESET- / I<< / Preset- | | |
| ▷I/PAP | PRESET+ / >>I / Preset+ | | |
| <<◁/S | TUNE- / << / Tune- | | |
| >>▷/P | TUNE+ / >> / Tune+ | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |