| Original | | Substituto | |
|---|---|---|---|
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | PIP | | Info / Angle |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | [<>] | | Picture / Format |
| | >I | | >>I / Preset+ |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | ? | | Smart / List |
| | I< | | I<< / Preset- |
| | 0 | | 0 |
| | Mute | | Mute / Dimmer |

| Original | | Substituto | |
|---|---|---|---|
| | i / OSD | | Display / Media |
| | Z / Disc Menu | | Menu / Home |
| | Up | | Up |
| | P+ | | CH+ / Page+ |
| | Left | | Left |
| | Vol - | | Vol - |
| | OK | | OK |
| | Right | | Right |
| | Vol + | | Vol + |
| | TXT | | Text / Goto |
| | << | | << / Tune- |
| | Down | | Down |
| | P- | | CH- / Page- |
| | TV-G | | Guide / EPG / -/-- |
| | >> | | >> / Tune+ |
| | Red / Image / I> | | Red / Netflix / Search |
| | Green / Timer | | Green / APP / Repeat |

| Original | Substituto | Original | Substituto |
|---|---|---|---|
| Play | Play / Slow | | |
| Yellow/Pause | Yellow / YouTube / Repeat | | |
| Pause | Pause / Step / Freeze | | |
| Blue/Sound | Blue / Prime Video / Random | | |
| Stop | Stop / Hold | | |
| Blue/Sound | Sound / Title | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Substituto | |
|---|---|---|---|
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | Audio | | Audio / Lang I/II |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | [<>] | | Zoom / Size |
| | >I | | >>I / Preset+ |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | ? | | Smart / List |
| | I< | | I<< / Preset- |
| | 0 | | 0 |
| | i / OSD | | Display / Media |

| Original | | Substituto | |
|---|---|---|---|
| | Disc Menu | | D.Menu / Top |
| | Disc Menu | | Menu / Home |
| | Up | | Up |
| | P+ | | CH+ / Page+ |
| | Left | | Left |
| | Vol - | | Vol - |
| | OK | | OK |
| | Right | | Right |
| | Vol + | | Vol + |
| | TXT | | Text / Goto |
| | << | | << / Tune- |
| | Down | | Down |
| | P- | | CH- / Page- |
| | TV-G | | Guide / EPG / -/-- |
| | >> | | >> / Tune+ |
| | Red/Picture | | Picture / Format |
| | Red/Picture | | Red / Netflix / Search |

| Original | Substituto | Original | Substituto |
|---|---|---|---|
| Green / Timer | Sleep / Timer | | |
| Play | Play / Slow | | |
| Green / Timer | Green / APP / Repeat | | |
| Yellow/Pause | Yellow / YouTube / Repeat | | |
| Pause | Pause / Step / Freeze | | |
| Blue/Sound | Sound / Title | | |
| Stop | Stop / Hold | | |
| Blue/Sound | Blue / Prime Video / Random | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

| Original | | Substituto | |
|---|---|---|---|
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | Audio | | Audio / Lang I/II |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | [<>] | | Zoom / Size |
| | >I | | >>I / Preset+ |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | ? | | Smart / List |
| | I< | | I<< / Preset- |
| | 0 | | 0 |
| | Mute | | Mute / Dimmer |

| Original | | Substituto | |
|---|---|---|---|
| | i / OSD | | Display / Media |
| | Z / Disc Menu | | Menu / Home |
| | Up | | Up |
| | P+ | | CH+ / Page+ |
| | Left | | Left |
| | Vol - | | Vol - |
| | OK | | OK |
| | Right | | Right |
| | Vol + | | Vol + |
| | TXT | | Text / Goto |
| | << | | << / Tune- |
| | Down | | Down |
| | P- | | CH- / Page- |
| | TV-G | | Guide / EPG / -/-- |
| | >> | | >> / Tune+ |
| | Red / Image / I> | | Red / Netflix / Search |
| | Red / Image / I> | | Shift + Play / Slow |

| Original | Substituto | Original | Substituto |
|---|---|---|---|
| Green/Timer | Green / APP / Repeat | | |
| Play | Play / Slow | | |
| Green/Timer | Sleep / Timer | | |
| Pause | Pause / Step / Freeze | | |
| Yellow/Pause | Yellow / YouTube / Repeat | | |
| Blue/Sound | Blue / Prime Video / Random | | |
| Stop | Stop / Hold | | |
| Blue/Sound | Sound / Title | | |

| Original | | Substituto | |
|---|---|---|---|
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | PIP/Audio | | Audio / Lang I/II |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | [<>] | | Zoom / Size |
| | >I | | >>I / Preset+ |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | ? | | Smart / List |
| | I< | | I<< / Preset- |
| | 0 | | 0 |
| | i/OSD | | Display / Media |

| Original | | Substituto | |
|---|---|---|---|
| Disc Menu | Z/Disc Menu | HOME MENU | Menu / Home |
| P+ | P+ | CH PAGE | CH+ / Page+ |
| P+ | Up | | Up |
| | Left | | Left |
| | Vol - | VOL | Vol - |
| OK | OK | OK | OK |
| | Right | | Right |
| | Vol + | VOL | Vol + |
| TXT | TXT | GOTO TEXT | Text / Goto |
| TXT | << | TUNE- | << / Tune- |
| P- | P- | CH PAGE | CH- / Page- |
| | Down | | Down |
| TV-G | TV-G | GUIDE EPG | Guide / EPG / -/-- |
| TV-G | >> | TUNE+ | >> / Tune+ |
| | Red/Image/I> | FORMAT PICTURE | Picture / Format |
| | Red/Image/I> | NETFLIX SEARCH | Red / Netflix / Search |
| | Green/Timer | APP REPEAT | Green / APP / Repeat |

| Original | Substituto | Original | Substituto |
|---|---|---|---|
| Play | Play / Slow | | |
| Green/Timer | Sleep / Timer | | |
| Yellow/Pause | Yellow / YouTube / Repeat | | |
| Pause | Pause / Step / Freeze | | |
| Blue/Sound | Blue / Prime Video / Random | | |
| Stop | Stop / Hold | | |
| Blue/Sound | Sound / Title | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |