Original		Substituto	
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
STILL	Still	SHIFT + STEP-FREEZE II	Shift + Pause / Step /
I/II	I/II	LANG I/II AUDIO	Audio / Lang I/II
⏻	Power	⏻	Power
SCAN	Scan	LIST SMART	Smart / List
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
PIP	PIP	FORMAT PICTURE	Picture / Format
DISPLAY	Display	MEDIA DISPLAY	Display / Media
1	1	TV 1	1
ABC@ 2	2	DVD 2	2
DEF 3	3	CD-STB 3	3
GHI$ 4	4	VIDEO 4	4
JKL% 5	5	TAPE 5	5
MNO^ 6	6	TUNER 6	6
PQR& 7	7	AUX-HDD 7	7
STUV 8	8	USB 8	8
WXYZ 9	9	BLUETOOTH 9	9

Original		Substituto	
TV/AV	TV/AV	RDS AV INPUT	AV / Input / RDS
*#()	0	HDMI-SAT 0	0
SWAP	Swap	RETURN BACK	Back / Return
P.STD	P.STD	OPT-TOOLS SETUP	Setup / OPT /
S.STD	S.STD	TITLE SOUND	Sound / Title
CH+	Up	▲	Up
CH+	CH+	+ CH PAGE	CH+ / Page+
VOL−	Vol -	VOL −	Vol -
VOL−	Left	◀	Left
MENU	Menu	HOME MENU	Menu / Home
MENU	OK	OK	OK
VOL+	Right	▶	Right
VOL+	Vol +	+ VOL	Vol +
CH−	CH-	CH PAGE −	CH- / Page-
CH−	Down	▼	Down
[=]	[=]	GOTO TEXT	Text / Goto
[+]	[+]	EQ SUBTITLE	Subtitle / EQ

Original		Substituto		Original	Substituto
	[/ =]	PROGRAM TV/RADIO	TV/Radio /		
	<<</[. . .]	TUNE-	<< / Tune-		
	>>/[?]	TUNE+	>> / Tune+		
	[X]	PC FAV MARKER	Fav / Marker / PC		
CH.LIST	Red/ ↑	NETFLIX SEARCH	Red / Netflix / Search		
	Green/ ←	APP REPEAT	Green / APP / Repeat		
	Yellow/ →	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
H.LOCK	Blue/Enter/H.Loc	Prime Video RANDOM	Blue / Prime Video / Random		
CH.LIST	White/ ↓/CH.List	-/-- GUIDE EPG	Guide / EPG / -/--		
TIMER	Pause/Timer	STEP-FREEZE	Pause / Step / Freeze		
ZOOM	[♦]/Zoom	SIZE ZOOM	Zoom / Size		
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		