Original		Substituto	
POWER	Power	POWER	Power
INPUT	Input	TIMER AV	AV
MONITOR ON	Monitor On	DISC NAV LIST	List
MONITOR OFF	Monitor Off	PROG SLEEP	Sleep
ENERGY SAVING	Energy Saving	SHIFT + ECO 3D	Shift + 3D
3D	3D	ECO 3D	3D
1	1	1	1
2ABC	2	2	2
3DEF	3	3	3
4GHI	4	4	4
5JKL	5	5	5
6MNO	6	6	6
7PQRS	7	7	7
8TUV	8	8	8
9WXYZ	9	9	9
0	0	0	0
1/a/A	1/a/A	-/-- GUIDE	Guide

Original		Substituto	
CLEAR	Clear	SHIFT + CLEAR EXIT	Shift + Exit
VOL +	Vol +	VOL +	Vol +
VOL -	Vol -	VOL -	Vol -
ARC	ARC	PICTURE FORMAT	Format
MUTE	Mute	MUTE	Mute
AUTO	Auto	HOME SMART	Smart
BRIGHTNESS (PAGE)	Brightness/Page	CH +	Ch +
BRIGHTNESS (PAGE)	Brightness/Page Down	CH -	Ch -
PSM	PSM	AD SUBT	Subt
INFO	Info	DISPLAY INFO	Info
W.BAL	W BAL	SEARCH TV/R	TV/R
SETTINGS	Settings	SETTINGS OPT	Options
S.MENU	S. Menu	TOP MENU MENU	Menu
BACK	Back	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
▲	Up	▲	Up
▼	Down	▼	Down

Original	Substituto	Original	Substituto
Right	Right		
Left	Left		
OK	Ok		
Title	Dual		
Simplink	Media		
Stop	Stop		
<<	<<		
Play	Play		
Pause	Pause		
>>	>>		
Red/Picture On	Red		
Green/Picture Of	Green		
Yellow	Yellow		
Blue	Blue		