Original	Substituto
Muting Receiver	Mute
Power Receiver	Power
Display	Info
Enter Receiver	Ok
Up Receiver	Up
Down Receiver	Down
Right Receiver	Right
Left Receiver	Left
Return Receiver	Back
Setup Receiver	Smart
Audio/Home	Media
Play Receiver	Play
I<< Receiver	I<<
>>I Receiver	>>I
<< Receiver	<<
>> Receiver	>>
Pause/Play reverse Receiver	Pause

Original	Substituto
Stop Receiver	Stop
1 Receiver	1
2 Receiver	2
3 Receiver	3
4 Receiver	4
5 Receiver	5
6 Receiver	6
7 Receiver	7
8 Receiver	8
9 Receiver	9
0/11 Receiver	0
+10/--/---10/Dimmer/D.Tun Receiver	Shift + Guide
CLR/Sleep/12 Receiver	Pre Ch
Movie Tv/Search Receiver	Red
Music/Repeat Receiver	Green
Game/Random Receiver	Yellow
THX/Play Mode Receiver	Blue

Original	Substituto	Original	Substituto
Vol + Receiver	Vol +	Movie/TV/Search	Options
Vol - Receiver	Vol -	Music/Repeat	Dual
CH/Disc/Album+ Receiver	Ch +	Game/Random	Subt
CH/Disc/Album- Receiver	Ch -	Stereo/Play Mode	TV/R
Power Tv	Shift + Power	1 Tv	Shift + 1
Input Tv	AV	2 Tv	Shift + 2
CH+ Tv	Shift + Ch +	3 Tv	Shift + 3
CH- Tv	Shift + Ch -	4 Tv	Shift + 4
Up Tv	Shift + Up	5 Tv	Shift + 5
Enter Tv	Shift + Ok	6 Tv	Shift + 6
Down Tv	Shift + Down	7 Tv	Shift + 7
Right Tv	Shift + Right	8 Tv	Shift + 8
Left Tv	Shift + Left	9 Tv	Shift + 9
Menu/Prev CH	Menu	0/11 Tv	Shift + 0
Guide/Top Menu	Shift + Menu	+10/--/--10 Tv	Guide
Return Tv	Shift + Back	CLR/Sleep/12	Shift + Pre Ch
Setup Tv	Shift + Smart	Vol + Tv	Shift + Dual

Original		Substituto		Original	Substituto
VOL	Vol - Tv	SHIFT + SETTINGS OPT	Shift + Options		
AUX	AUX	REPEAT TEXT	Text		
TV/CD	TV / CD	PICTURE FORMAT	Format		
CBL/SAT	CBL/SAT	ECO 3D	3D		
FM	FM	SHIFT + AD SUBT	Shift + Subt		
BD/DVD	DVD / BD	SHIFT + REPEAT TEXT	Shift + Text		
GAME	Game	SHIFT + SEARCH TV/R	Shift + TV/R		
STB/DVR	VCR / DVR	SHIFT + TIMER AV	Shift + AV		
PC	PC	ZOOM	Eject		
USB	USB	DISC NAV LIST	List		
NET	NET	SHIFT + ZOOM	Shift + Eject		

Original	Substituto
Power BD/DVD	Power
Menu/Prev CH	Menu
Top Menu/Guide BD/DVD	Options
Setup BD/DVD	Smart
Return BD/DVD	Back
Home/Audio	Media
Enter BD/DVD	Ok
Up BD/DVD	Up
Down BD/DVD	Down
Right BD/DVD	Right
Left BD/DVD	Left
I << BD/DVD	I <<
>>I BD/DVD	>>I
<< BD/DVD	<<
>> BD/DVD	>>
Play BD/DVD	Play
Pause/Play rev. BD/DVD	Pause

Original	Substituto
Stop BD/DVD	Stop
Movie Tv/Search BD/DVD	Red
Music/Repeat	Green
Game/Random	Yellow
Stereo/Play Mode BD/DVD	Blue
1 BD/DVD	1
2 BD/DVD	2
3 BD/DVD	3
4 BD/DVD	4
5 BD/DVD	5
6 BD/DVD	6
7 BD/DVD	7
8 BD/DVD	8
9 BD/DVD	9
0/11 BD/DVD	0
+10/--/--10/D.Tu Dimmer BD/DVD	Guide
CLR/Sleep/12	Pre Ch

BD/DVD

Original	Substituto	Original	Substituto
CBL/SAT	Text	<< CBL/SAT	Shift + Ch -
Vol + Receiver	Vol +	>> CBL/SAT	Shift + Ch +
Vol - Receiver	Vol -	Play CBL/SAT	3D
Power CBL/SAT	Shift + Power	Movie Tv/Search CBL/SAT	Dual
CH Disc/Album+ CBL/SAT	Ch +	Music/Repeat CBL/SAT	Subt
CH Disc/Album- CBL/SAT	Ch -	Game/Random	AV
Menu/Prev CH CBL/SAT	Shift + Menu	Stereo/Play Mode CBL/SAT	Format
Top Menu/Guide CBL/SAT	Shift + Options	1 CBL/SAT	Shift + 1
Return CBL/SAT	Shift + Back	2 CBL/SAT	Shift + 2
Setup CBL/SAT	Shift + Smart	3 CBL/SAT	Shift + 3
Up CBL/SAT	Shift + Up	4 CBL/SAT	Shift + 4
Enter CBL/SAT	Shift + Ok	5 CBL/SAT	Shift + 5
Down CBL/SAT	Shift + Down	6 CBL/SAT	Shift + 6
Right CBL/SAT	Shift + Right	7 CBL/SAT	Shift + 7
Left CBL/SAT	Shift + Left	8 CBL/SAT	Shift + 8
Pause/Play rev. CBL/SAT	Shift + Pause	9 CBL/SAT	Shift + 9
Stop CBL/SAT	Shift + Stop	0/11 CBL/SAT	Shift + 0

Original	Substituto	Original	Substituto
BD/DVD DVD/ BD	SEARCH TV/R TV/ R		

Original	Substituto	Original	Substituto
Power CD	Power	Stop CD	Stop
CH/Disc+ CD	Ch +	Movie Tv/Search	Red
CH/Disc- CD	Ch -	Music/Repeat	Green
Return CD	Back	Game/Random	Yellow
Setup CD	Smart	Stereo/Play Mode	Blue
Home/Audio CD	Media	1 CD	1
Up CD	Up	2 CD	2
Down CD	Down	3 CD	3
Right CD	Right	4 CD	4
Left CD	Left	5 CD	5
Enter CD	Ok	6 CD	6
I << CD	I <<	7 CD	7
>>I CD	>>I	8 CD	8
<< CD	<<	9 CD	9
>> CD	>>	0/11 CD	0
Play CD	Play	+10/--/--10/D.Tu Dimmer CD	Guide
Pause CD	Pause	CLR/Sleep/12	Pre Ch

CD

Original		Substituto		Original	Substituto
VOL	Vol + Receiver	VOL	Vol +		
VOL	Vol - Receiver	VOL	Vol -		
TV/CD	TV/CD	SEARCH TV/R	TV/R		

Original	Substituto
Power Receiver Zone 2	Power
Vol + Zone 2	Vol +
Vol - Zone 2	Vol -
CH Disc/Album+ Zone 2	Ch +
CH Disc/Album- Zone 2	Ch -
Up Zone 2	Up
Enter Zone 2	Ok
Down Zone 2	Down
Right Zone 2	Right
Left Zone 2	Left
Return Zone 2	Back
Setup Zone 2	Smart
Audio Zone 2	Media
I << Zone 2	I <<
>>I Zone 2	>>I
Play Zone 2	Play
>> Zone 2	>>

Original	Substituto
<< Zone 2	<<
Pause Zone 2	Pause
Stop Zone 2	Stop
Movie Tv/Search Zone 2	Red
Music/Repeat	Green
Game/Random	Yellow
Stereo/Play Mode Zone 2	Blue
1 Zone 2	1
2 Zone 2	2
3 Zone 2	3
4 Zone 2	4
5 Zone 2	5
6 Zone 2	6
7 Zone 2	7
8 Zone 2	8
9 Zone 2	9
0/11 Zone 2	0

Original	Substituto	Original	Substituto
+10/- - /- - 10/D.Tuning Dimmer Zone 2	Guide		
CLR/Sleep/12	Pre Ch		