Original	Substituto	Original	Substituto
Standby	Power	6	6
Record	Rec	7	7
Up	Up	8	8
Left	Left	9	9
Right	Right	0	0
Down	Down	Vol +	Vol +
->	Smart	Vol -	Vol -
OK	Ok	Mute	Mute
Menu	Menu	P<P	Pre Ch
Clear	Exit	P+	Ch +
Timer	AV	P-	Ch -
SV/V+	Media	Play	Play
1	1	<<	<<
2	2	>>	>>
3	3	>I / Index	>>I
4	4	Stop	Stop
5	5	>I < Still	Pause

Original		Substituto	
	Teletext		Text
	Hold		Red
	Reveal		Green
	Size		Yellow
	Cancel		Blue