Original		Substituto	
	Power		Power
INP TV	Input TV	PROGRAM TV/RADIO	TV/Radio /
PUT AV	Input Av	RDS AV INPUT	AV / Input / RDS
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	Up		Up
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Left		Left
OK	OK	OK	OK
	Right		Right
MENU	Menu	HOME MENU	Menu / Home
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
ASPECT	[+]/Aspect	FORMAT PICTURE	Picture / Format

Original		Substituto	
VIERA Link	Link Vieta	LIST SMART	Smart / List
OPTION	Option	OPT-TOOLS SETUP	Setup / OPT /
DIRECT TV REC	Direct Tv Rec	SHIFT + REC MODE	Shift + Rec / Rec Mode
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
i	i	ANGLE INFO	Info / Angle
0 VCR	0/VCR	HDMI-SAT 0	0
0 VCR	0/VCR	SHIFT + VIDEO 4	Shift + 4
	Mute	DIMMER MUTE	Mute / Dimmer
	CH+	+ CH PAGE	CH+ / Page+

Original	Substituto	Original	Substituto
Vol +	Vol +	Play DVD	Play / Slow
CH-	CH- / Page-		
Vol -	Vol -		
[≡] / Text	Text / Goto		
[≡◆] / STTL	Subtitle / EQ		
[≡i] / Index	Display / Media		
[≡+] / Hold	Shift + Stop /		
Power DVD	Shift + Power		
Rec DVD	Rec / Rec Mode		
Programme Down	Shift + CH- /		
Programme Up	Shift + CH+ /		
<<< / I << DVD	<< / Tune-		
<<< / I << DVD	I << / Preset-		
>>> / >>I DVD	>>I / Preset+		
>>> / >>I DVD	>> / Tune+		
Stop DVD	Stop / Hold		
Pause/Step DVD	Pause / Step / Freeze		

Original	Substituto
Power DVD	Power
Rec DVD	Rec / Rec Mode
Programme Down	CH- / Page-
Programme Up	CH+ / Page+
I << DVD	I << / Preset-
I << DVD	<< / Tune-
>>I DVD	>>I / Preset+
>>I DVD	>> / Tune+
Stop DVD	Stop / Hold
Pause/Step DVD	Pause / Step / Freeze
Play DVD	Play / Slow

Original	Substituto

Original	Substituto
Power VCR	Power
Rec VCR	Rec / Rec Mode
Programme Down	CH- / Page-
Programme Up	CH+ / Page+
<<| << VCR	I << / Preset-
<<| << VCR	<< / Tune-
>>| >>I VCR	>> / Tune+
>>| >>I VCR	>>I / Preset+
Stop VCR	Stop / Hold
Pause/Step VCR	Pause / Step / Freeze
Play VCR	Play / Slow

Original	Substituto