Original	Substituto
TV/TEXT — TV / Text	GOTO TEXT — Text / Goto
--	PC FAV MARKER — Fav / Marker / PC
REPLAY — Replay	OPT-TOOLS SETUP — Setup / OPT /
OSD/DISPLAY — OSD / Display	MEDIA DISPLAY — Display / Media
PROG/CHECK — Prog / Check	SHIFT + PROGRAM TV/RADIO — Shift + TV/Radio / Program
DATE – — Date-	SHIFT + ◀ — Shift + Left
DATE + — Date+ / Green	SHIFT + ▶ — Shift + Right
TV ASPECT — TV Aspect	PROGRAM TV/RADIO — TV/Radio /
RESET — Reset	RETURN BACK — Back / Return
ON – — On-	SHIFT + ▼ — Shift + Down
ON + — On+ / Yellow	SHIFT + ▲ — Shift + Up
OFF – — Off-	SHIFT + MEDIA DISPLAY — Shift + Display / Media
OFF + — Off+ / Blue	SHIFT + LIST SMART — Shift + Smart / List
SP/LP — SP/LP	FORMAT PICTURE — Picture / Format
OFF + — Off+ / Blue	Prime Video RANDOM — Blue / Prime Video / Random
VIDEO PLUS+ — Video Plus +	LIST SMART — Smart / List
INPUT SELECT AV — AV / Input Selec	RDS AV INPUT — AV / Input / RDS

Original	Substituto
TRACKING/V-LOCK ^ — Tracking/V-Lock	SHIFT + CH PAGE + — Shift + CH+ /
TRACKING/V-LOCK v — Tracking/V-Lock	SHIFT + CH PAGE – — Shift + CH- /
v — V	CH PAGE – — CH- / Page-
^ — Λ / Red	CH PAGE + — CH+ / Page+
TIMER REC — Timer Rec	TIMER SLEEP — Sleep / Timer
^ — Λ / Red	NETFLIX SEARCH — Red / Netflix / Search
■ — Stop / Down	HOLD ■ — Stop / Hold
DATE + — Date+ / Green	APP REPEAT — Green / APP / Repeat
▼ — Stop / Down	▼ — Down
ON + — On+ / Yellow	YouTube REPEAT A-B — Yellow / YouTube / Repeat
INDEX ⏮ — I<< Index-	PRESET- ⏮ — I<< / Preset-
INDEX ⏭ — >>I Index+	PRESET+ ⏭ — >>I / Preset+
EXIT — Exit	CLEAR EXIT CANCEL — Exit / Cancel / Clear
▶▶ — >> / Right	▶ — Right
▶▶ — >> / Right	TUNE+ ▶▶ — >> / Tune+
◀◀ — << / Left	TUNE- ◀◀ — << / Tune-
◀◀ — << / Left	◀ — Left

Original	Substituto	Original	Substituto
Play / Up	Up	Power	Power
Play / Up	SLOW Play / Slow	VOLUME Volume+	VOL + Vol +
OK	OK OK	Volume-	VOL - Vol -
CANCEL Cancel	SHIFT + CLEAR EXIT CANCEL Shift + Exit / Cancel / Clear	REC Rec	REC MODE Rec / Rec Mode
AUDIO Audio	LANG I/II AUDIO Audio / Lang I/II	Pause / Step	STEP-FREEZE Pause / Step / Freeze
1 1	TV 1 1	MENU Menu	HOME MENU Menu / Home
2 2	DVD 2 2		
3 3	CD-STB 3 3		
4 4	VIDEO 4 4		
5 5	TAPE 5 5		
6 6	TUNER 6 6		
SEARCH Search	SHIFT + NETFLIX SEARCH Shift + Red / Netflix /		
7 7	AUX-HDD 7 7		
8 8	USB 8 8		
9 9	BLUETOOTH 9 9		
0 0	HDMI-SAT 0 0		
-/--	-/-- GUIDE EPG Guide / EPG / -/--		