Original		Substituto	
	Power		Power
QUICK OSD	Quick OSD	APP MEDIA	Media
FL SELECT	FL Select	HOME SMART	Smart
OPEN/CLOSE	Open/Close	ZOOM	Eject
ADVANCED SURROUND	Advanced	SEARCH TV/R	TV/R
PICTURE MODE	Picture Mode	PICTURE FORMAT	Format
REPEAT	Repeat	REPEAT TEXT	Text
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Substituto	
≥10	+10	-/-- GUIDE	Guide
CANCEL	Cancel	CLEAR EXIT	Exit
PLAY SPEED	Play Speed	A	Red
DIALOGUE ENHANCER	Dialogue	B	Green
MANUAL SKIP	Manual Skip	C	Yellow
QUICK REPLAY	Quick Replay	DISC NAV LIST	List
SKIP	I<< Skip	<<	I<<
SKIP	Skip >>I	>>	>>I
SLOW/SEARCH	<< Slow/Search	<<	<<
SLOW/SEARCH	Slow/Search >>	>>	>>
STOP	Stop		Stop
PAUSE	Pause	II	Pause
PLAY	Play	PLAY MODE	Play
TOP MENU	Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
MENU	Menu	TOP MENU MENU	Menu
FUNCTIONS	Functions	E-MANUAL D.MENU	D. Menu
RETURN	Return	RETURN BACK	Back

Original		Substituto		Original	Substituto
	Up		Up		
	Down		Down		
	Right		Right		
	Left		Left		
ENTER	Enter	OK	Ok		
SUBTITLE	Subtitle	AD SUBT	Subt		
AUDIO	Audio	SOUND DUAL	Dual		
ANGLE/PAGE	Angle/Page	D	Blue		
PLAY MODE	Play Mode	SHIFT +	PLAY MODE Shift + Play		
SETUP	Setup	SETTINGS OPT	Options		
TRANSFER MODE	Transfer Mode	TIMER AV	AV		
ZOOM	Zoom	SHIFT +	ZOOM Shift + Eject		
DNR	DNR	ECO 3D	3D		