| Original | | Substituto | |
|---|---|---|---|
| | Power | | Power |
| TV ASPECT | Tv Aspect / AV Lin | ECO 3D | 3D |
| TV / TEXT | Tv/ Text | REPEAT TEXT | Text |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| INPUT SELECT AV | AV/ I nput Sel ec | TIMER AV | AV |
| -/-- | - / - - | -/-- GUIDE | Gui de |
| VOLUME + | Vol + | + VOL | Vol + |
| | Vol - | VOL − | Vol - |

| Original | | Substituto | |
|---|---|---|---|
| CKING/V-LOCK + | Tracki ng/ V. Lock+ | + CH | Ch + |
| − | Tracki ng/ V. Lock- | CH − | Ch - |
| | Prog. / Check Up | SHIFT + + CH | Shi f t + Ch + |
| PROG./CHEC | Prog. / Check Down | SHIFT + CH − | Shi f t + Ch - |
| | Red | A | Red |
| + DATE | Gr een | B | Gr een |
| + ON | Yel l ow | C | Yel l ow |
| + OFF | Bl ue | D | Bl ue |
| + OFF | Of f + | | Up |
| OFF − | Of f - | | Down |
| + ON | On+ | | Ri ght |
| ON − | On- | | Lef t |
| + DATE | Dat e+ | HOME SMART | Smart |
| DATE − | Dat e- | APP MEDIA | Medi a |

| Original | | Substituto | |
|---|---|---|---|
| | Power | | Power |
| DIRECT TV REC | Direct Tv Rec | SEARCH TV/R | TV/R |
| TV ASPECT | Tv Aspect/AV Lin | ECO 3D | 3D |
| TV/TEXT | Tv/Text | REPEAT TEXT | Text |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| -/-- | -/-- | -/-- GUIDE | Guide |
| INPUT SELECT AV | AV/Input Selec | TIMER AV | AV |
| TRACKING/V-LOCK + | Tracking/V-Lock+ | + CH | Ch + |

| Original | | Substituto | |
|---|---|---|---|
| | Tracking/V-Lock- | CH − | Ch - |
| VOLUME + | Vol + | + VOL | Vol + |
| − | Vol - | VOL − | Vol - |
| LIBRARY/SEARCH | Library/Search | HOME SMART | Smart |
| INDEX | Index << | << | Index << |
| INDEX >>I | Index >>I | >>I | >>I |
| SV/V+ | SV/V+ | APP MEDIA | Media |
| STILL ALBUM | -/Still Albu | RETURN BACK | Back |
| REPLAY | Replay | AD SUBT | Subt |
| II/I▶ | Pause/Step | II | Pause |
| REC | Rec | REC MODE | Rec |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| OK | OK | OK | Ok |
| | Play | PLAY MODE | Play |

| Original | | Substituto | |
|---|---|---|---|
| | Stop | | Stop |
| | >> | | >> |
| | << | | << |
| MENU | Menu | TOP MENU MENU | Menu |
| EXIT | Exit | CLEAR EXIT | Exit |
| | Prog. / Check Up | SHIFT + CH + | Shift + Ch + |
| PROG./CHEC | Prog. / Check Down | SHIFT + CH − | Shift + Ch - |
| + DATE | Date+ | SHIFT + HOME SMART | Shift + Smart |
| DATE − | Date- | SHIFT + APP MEDIA | Shift + Media |
| + ON | On+ | B | Green |
| ON − | On- | A | Red |
| + OFF | Off + | D | Blue |
| OFF − | Off - | C | Yellow |
| PROG./CHECK | Prog. Check | PROG SLEEP | Sleep |
| CANCEL | Cancel | DISC NAV LIST | List |
| SP/LP/EP | SP/ LP/ EP | PICTURE FORMAT | Format |
| TIMER | Timer | SHIFT + TIMER AV | Shift + AV |

| Original | | Substituto | |
|---|---|---|---|
| I-TIMER | I-Timer | SETTINGS OPT | Options |
| AUDIO | Audio | SOUND DUAL | Dual |
| OSD/DISPLAY | OSD/Display | DISPLAY INFO | Info |
| RESET | Reset | E-MANUAL D.MENU | D. Menu |