Original		Substituto	
	Power		Power
	Power Tv	SHIFT +	Shift + Power
VOL	Vol + Tv	VOL	Vol +
CH	CH+ Tv	SHIFT + CH PAGE	Shift + CH+ /
DRIVE SELECT	Drive Select	MEDIA DISPLAY	Display / Media
INPUT AV	AV Input Tv	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
VOL	Vol - Tv	VOL	Vol -
CH	CH- Tv	SHIFT + CH PAGE	Shift + CH- /
1	1	TV 1	1
2abc	2	DVD 2	2
3def	3	CD - STB 3	3
PAGE CH	CH/Page+	CH PAGE	CH+ / Page+
4ghi	4	VIDEO 4	4
5jkl	5	TAPE 5	5
6mno	6	TUNER 6	6
CH	CH/Page-	CH PAGE	CH- / Page-
7pqrs	7	AUX - HDD 7	7

Original		Substituto	
8tuv	8	USB 8	8
9wxyz	9	BLUETOOTH 9	9
INTERNET	Internet	LIST SMART	Smart / List
LAST VIEW	Last View	PC FAV MARKER	Fav / Marker / PC
0	0	HDMI - SAT 0	0
RADIO/TV	Radio/Tv	PROGRAM TV/RADIO	TV/Radio /
	Skipe	SHIFT + LIST SMART	Shift + Smart / List
SKIP	I<< Skip	PRESET-	I<< / Preset-
SKIP	Skip >>I	PRESET+	>>I / Preset+
SLOW/SEARCH REW	<< Slow/Search/Rewi	TUNE-	<< / Tune-
SEARCH WIND LIVE TV	Slow/search >>	TUNE+	>> / Tune+
STOP	Stop	HOLD	Stop / Hold
PAUSE PAUSE LIVE TV	Pause/Pause Live	STEP - FREEZE	Pause / Step / Freeze
PLAY/x1.3	Play	SLOW	Play / Slow
STATUS	i/Status	ANGLE INFO	Info / Angle
EXIT	X/Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Substituto	
	Pop-Up menu/Direct	TOP MENU D.MENU	D. Menu / Top
	Left		Left
	Up		Up
OK	OK	OK	OK
	Right		Right
FUNCTION MENU	Function Menu	HOME MENU	Menu / Home
OPTION	Option	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
R	Red	NETFLIX SEARCH	Red / Netflix / Search
G	Green	APP REPEAT	Green / APP / Repeat
Y	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
B	Blue	Prime Video RANDOM	Blue / Prime Video / Random
REC	Rec	REC MODE	Rec / Rec Mode
REC MODE	Rec Mode	SHIFT + REC MODE	Shift + Rec / Rec Mode
TEXT	Text	GOTO TEXT	Text / Goto
STTL	STTL	EQ SUBTITLE	Subtitle / EQ

Original		Substituto	
PROG/CHECK	Prog/Check	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program
CHAPTER	Chapter	SIZE ZOOM	Zoom / Size
TIME SLIP	Time Slip	FORMAT PICTURE	Picture / Format
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
INPUT SELECT	Input Select	RDS AV INPUT	AV / Input / RDS
DEL	DEL	TIMER SLEEP	Sleep / Timer
MANUAL -10s	Manual Skip -10s	SHIFT +	Shift + Left
SKIP +60s	Manual Skip +60s	SHIFT +	Shift + Right