Mandis shop

Panasonic N2QAYC000081

Original	Substituto
Power	Power
Eject iPod	SHIFT + SURROUND (Shift + Eject / Surround)
Eject CD	SURROUND (Eject / Surround)
iPod USB	LIST SMART (Smart / List)
CD/Radio	PROGRAM TV/RADIO (TV/Radio /)
Bluetooth	BLUETOOTH 9 (9)
I<<<<	TUNE- << (<< / Tune-)
Play	SLOW Play (Play / Slow)
Pause	STEP-FREEZE Pause (Pause / Step / Freeze)
>>>>	TUNE+ >> (>> / Tune+)
Stop	HOLD Stop (Stop / Hold)
VOL–	VOL – (Vol -)
VOL+	VOL + (Vol +)
SETUP	OPT-TOOLS SETUP (Setup / OPT /)
MUTE	DIMMER MUTE (Mute / Dimmer)
iPod MENU DISPLAY	MEDIA DISPLAY (Display / Media)
SOUND	TITLE SOUND (Sound / Title)

Original	Substituto
PLAY MENU (Play Menu)	APP REPEAT (Green / APP / Repeat)
Album Up	Up
OK	OK
Album Down	Down

https://www.mandis.tv/p/Panasonic/1665-634-mando-de-substituicao-para-Panasonic-N2QAYC000081.htm