Original		Substituto	
STANDBY	Standby		Power
	Open/Close	ZOOM	Eject
MODE	Mode	REPEAT TEXT	Text
A-B	A-B	SHIFT + PLAY MODE	Shift + Play
DIM	DIM	RETURN BACK	Back
DISPLAY	Display	DISPLAY INFO	Info
SYSTEM MENU	System Menu	TOP MENU MENU	Menu
DISC MENU	Disc Menu	E-MANUAL D.MENU	D. Menu
ZOOM	Zoom	SHIFT + ZOOM	Shift + Eject
CH LEVEL	CH Level	SEARCH TV/R	TV/R
OK	OK	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	>I		>>I
	I<		I<<

Original		Substituto	
+	Vol +	+ VOL	Vol +
–	Vol -	VOL –	Vol -
MUTE	Mute	MUTE	Mute
SURROUND	Surround	SOUND DUAL	Dual
▶II	Play	PLAY MODE ▶	Play
▶II	Pause	II	Pause
■	Stop	■	Stop
LOUDNESS	Loudness	D	Blue
DSC	DSC	A	Red
DBB	DBB	B	Green
CLOCK/RDS	Clock/RDS	C	Yellow
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6

Original		Substituto		Original		Substituto	
7	7	7	7				
8	8	8	8				
9	9	9	9				
0	0	0	0				
SLEEP/TIMER	Sleep/Timer	CLEAR EXIT	Exit				
SUBTITLE	Subtitle	AD SUBT	Subt				
AUDIO	Audio	DISC NAV LIST	List				
PROGRAM	Program	PROG SLEEP	Sleep				
GOTO/STEREO	Goto/Stereo	-/-- GUIDE	Guide				
ANGLE	Angle	TIMER AV	AV				

Original		Substituto	
STANDBY	Standby		Power
	Open/Close	ZOOM	Eject
DIM	DIM	RETURN BACK	Back
CH LEVEL	CH Level	SEARCH TV/R	TV/R
	Left		Left
	Right		Right
	>I		>>I
	I<		I<<
	Vol +	VOL +	Vol +
	Vol -	VOL -	Vol -
MUTE	Mute	MUTE	Mute
SURROUND	Surround	SOUND DUAL	Dual
	Stop		Stop
LOUDNESS	Loudness	D	Blue
DSC	DSC	A	Red
DBB	DBB	B	Green
CLOCK/RDS	Clock/RDS	C	Yellow

Original		Substituto	
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
SLEEP/TIMER	Sleep/Timer	CLEAR EXIT	Exit
PROGRAM	Program	PROG SLEEP	Sleep
GOTO/STEREO	Goto/Stereo	-/-- GUIDE	Guide

Original		Substituto	
STANDBY	Standby		Power
	Open/Close	ZOOM	Eject
MODE	Mode	REPEAT TEXT	Text
A-B	A-B	SHIFT + PLAY MODE	Shift + Play
DIM	DIM	RETURN BACK	Back
DISPLAY	Display	DISPLAY INFO	Info
SYSTEM MENU	System Menu	TOP MENU MENU	Menu
DISC MENU	Disc Menu	E-MANUAL D.MENU	D. Menu
ZOOM	Zoom	SHIFT + ZOOM	Shift + Eject
CH LEVEL	CH Level	SEARCH TV/R	TV/R
OK	OK	OK	Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	>I		>>I
	I<		I<<

Original		Substituto	
+	Vol +	+ VOL	Vol +
–	Vol -	VOL –	Vol -
MUTE	Mute	MUTE	Mute
SURROUND	Surround	SOUND DUAL	Dual
▶II	Play	PLAY MODE ▶	Play
▶II	Pause	II	Pause
■	Stop	■	Stop
LOUDNESS	Loudness	D	Blue
DSC	DSC	A	Red
DBB	DBB	B	Green
CLOCK/RDS	Clock/RDS	C	Yellow
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6

Original		Substituto		Original		Substituto	
7	7	7	7				
8	8	8	8				
9	9	9	9				
0	0	0	0				
SLEEP/TIMER	Sleep/Timer	CLEAR EXIT	Exit				
SUBTITLE	Subtitle	AD SUBT	Subt				
AUDIO	Audio	DISC NAV LIST	List				
PROGRAM	Program	PROG SLEEP	Sleep				
GOTO/STEREO	Goto/Stereo	-/-- GUIDE	Guide				
ANGLE	Angle	TIMER AV	AV				

Original	Substituto	Original	Substituto
Standby	Power		
Open/Close	Eject		
DIM	Back		
CH Level	TV/R		
Vol +	Vol +		
Vol -	Vol -		
Mute	Mute		
Surround	Dual		
Loudness	Blue		
DSC	Red		
DBB	Green		
Clock/RDS	Yellow		
Sleep/Timer	Exit		