Original		Substituto	
	Power Tv		Power
	Av Tv	TIMER AV	AV
MENU	Menu Tv	TOP MENU MENU	Menu
	Up Tv		Up
	Down Tv		Down
	Left Tv		Left
	Right Tv		Right
OK	Ok Tv	OK	Ok
INFO	Info Tv	DISPLAY INFO	Info
EXIT	Exit Tv	CLEAR EXIT	Exit
	Red Tv	A	Red
	Green Tv	B	Green
	Yellow Tv	C	Yellow
	Blue Tv	D	Blue
+ VOL	Vol + Tv	+ VOL	Vol +
VOL −	Vol - Tv	VOL −	Vol -
	Mute Tv	MUTE	Mute

Original		Substituto	
P•P	Back Tv	RETURN BACK	Back
+ CH	Ch+ Tv	+ CH	Ch +
CH −	Ch- Tv	CH −	Ch -
▼P[≡]	▼P[≡] Tv		I <<
▲P[ ]	▲P[ ] Tv		>>I
	<< Tv		<<
	>> Tv		>>
	Stop Tv		Stop
	Play Tv	PLAY MODE	Play
1	1 Tv	1	1
2	2 Tv	2	2
3	3 Tv	3	3
4	4 Tv	4	4
5	5 Tv	5	5
6	6 Tv	6	6
7	7 Tv	7	7
8	8 Tv	8	8

Original		Substituto	
9	9 Tv	9	9
0	0 Tv	0	0
* TXT	Text Tv	REPEAT TEXT	Text
# HELP	#Help Tv	FAV PRE-CH	Pre Ch
▼P [≡]	▼P [≡] Tv2	SHIFT + I<<	Shift + I<<
▲P [ ]	▲P [ ] Tv2	SHIFT + >>I	Shift + >>I
●	Rec Tv2	SHIFT + REC MODE ●	Shift + Rec
▶	Play Tv2	SHIFT + PLAY MODE ▶	Shift + Play
AV	Av Tv2	SHIFT + TIMER AV	Shift + AV
<<	<< Tv2	SHIFT + <<	Shift + <<
>>	>> Tv2	SHIFT + >>	Shift + >>
⏻	Power Tv2	SHIFT + ⏻	Shift + Power
GUIDE	Guide Tv2	SHIFT + -/-- GUIDE	Shift + Guide
MENU	Menu Tv2	SHIFT + TOP MENU MENU	Shift + Menu
▲	Up Tv2	SHIFT + ▲	Shift + Up
◀	Left Tv2	SHIFT + ◀	Shift + Left
▶	Right Tv2	SHIFT + ▶	Shift + Right

Original		Substituto	
▼	Down Tv2	SHIFT + ▼	Shift + Down
OK	Ok Tv2	SHIFT + OK	Shift + Ok
INFO	Info Tv2	SHIFT + DISPLAY INFO	Shift + Info
●	Green Tv2	SHIFT + B	Shift + Green
●	Red Tv2	SHIFT + A	Shift + Red
EXIT	Exit Tv2	SHIFT + CLEAR EXIT	Shift + Exit
●	Yellow Tv2	SHIFT + C	Shift + Yellow
●	Blue Tv2	SHIFT + D	Shift + Blue
P•P	Back Tv2	SHIFT + RETURN BACK	Shift + Back
CH+	Ch+ Tv2	SHIFT + CH+	Shift + Ch +
CH-	Ch- Tv2	SHIFT + CH-	Shift + Ch -
■	Stop Tv2	SHIFT + ■	Shift + Stop
⏸	Pause Tv2	SHIFT + ⏸	Shift + Pause
1	1 Tv2	SHIFT + 1	Shift + 1
2	2 Tv2	SHIFT + 2	Shift + 2
3	3 Tv2	SHIFT + 3	Shift + 3
4	4 Tv2	SHIFT + 4	Shift + 4

Original		Substituto		Original	Substituto
5	5 Tv2	SHIFT + 5	Shift + 5		
6	6 Tv2	SHIFT + 6	Shift + 6		
7	7 Tv2	SHIFT + 7	Shift + 7		
8	8 Tv2	SHIFT + 8	Shift + 8		
9	9 Tv2	SHIFT + 9	Shift + 9		
0	0 Tv2	SHIFT + 0	Shift + 0		
* TXT	Text Tv2	SHIFT + REPEAT TEXT	Shift + Text		
# HELP	#Help Tv2	SHIFT + FAV PRE-CH	Shift + Pre Ch		

Original	Substituto	Original	Substituto
Power DVD	Power	Mute DVD/DVR	Mute
AV DVD/DVR	AV	Back DVD/DVR	Back
Guide DVD/DVR	Guide	Ch+ DVD/DVR	Ch +
Menu DVD/DVR	Menu	▼P[≡] DVD/DVR	I <<
Info DVD/DVR	Info	Ch- DVD/DVR	Ch -
Exit DVD/DVR	Exit	▲P[ ] DVD/DVR	>>I
Up DVD/DVR	Up	<< DVD/DVR	<<
Down DVD/DVR	Down	>> DVD/DVR	>>
Left DVD/DVR	Left	Play DVD/DVR	Play
Right DVD/DVR	Right	Pause DVD/DVR	Pause
Ok DVD/DVR	Ok	Stop DVD/DVR	Stop
Red DVD/DVR	Red	Rec DVD/DVR	Rec
Green DVD/DVR	Green	1 DVD/DVR	1
Yellow	Yellow	2 DVD/DVR	2
Blue DVD/DVR	Blue	3 DVD/DVR	3
Vol + DVD/DVR	Vol +	4 DVD/DVR	4
Vol - DVD/DVR	Vol -	5 DVD/DVR	5

Original		Substituto	
6	6 DVD/DVR	6	6
7	7 DVD/DVR	7	7
8	8 DVD/DVR	8	8
9	9 DVD/DVR	9	9
0	0 DVD/DVR	0	0
* TXT	Text DVD/DVR	REPEAT TEXT	Text
# HELP	#Help DVD/DVR	FAV PRE-CH	Pre Ch
	Power DVR	SHIFT +	Shift + Power

Original	Substituto

Original		Substituto	
	Power		Power
	Menu		Menu
	Guide		Guide
	AV SAT/CABLE		AV
	Up SAT/CABLE		Up
	Down		Down
	Left SAT/CABLE		Left
	Right		Right
	Ok SAT/CABLE		Ok
	Info SAT/CABLE		Info
	Exit SAT/CABLE		Exit
	Red SAT/CABLE		Red
	Green		Green
	Yellow SAT/CABLE		Yellow
	Blue SAT/CABLE		Blue
	Vol +		Vol +
	Vol - SAT/CABLE		Vol -

Original		Substituto	
	Mute		Mute
	Back		Back
	Ch+ SAT/CABLE		Ch +
	Ch- SAT/CABLE		Ch -
	<< SAT/CABLE		<<
	>> SAT/CABLE		>>
	Stop SAT/CABLE		Stop
	Rec SAT/CABLE		Rec
	Play SAT/CABLE		Play
	Pause		Pause
	1 SAT/CABLE		1
	2 SAT/CABLE		2
	3 SAT/CABLE		3
	4 SAT/CABLE		4
	5 SAT/CABLE		5
	6 SAT/CABLE		6
	7 SAT/CABLE		7

Original		Substituto		Original	Substituto
8	8 SAT/ CABLE	8	8		
9	9 SAT/ CABLE	9	9		
0	0 SAT/ CABLE	0	0		
# HELP	#Help	FAV PRE-CH	Pre Ch		
* TXT	Text SAT/ CABLE	REPEAT TEXT	Text		

Original		Substituto	
	Power DVBT		Power
	Gui de DVBT	GUIDE	Gui de
MENU	Menu DVBT	TOP MENU MENU	Menu
	Up DVBT		Up
	Down DVBT		Down
	Left DVBT		Left
	Ri ght DVBT		Ri ght
OK	Ok DVBT	OK	Ok
INFO	I nf o DVBT	DISPLAY INFO	I nf o
	Red DVBT	A	Red
	Gr een DVBT	B	Gr een
	Yel l ow DVBT	C	Yel l ow
	Bl ue DVBT	D	Bl ue
+ VOL	Vol + DVBT	+ VOL	Vol +
VOL −	Vol - DVBT	VOL −	Vol -
	Mut e DVBT	MUTE	Mut e
P.P	Back DVBT	RETURN BACK	Back

Original		Substituto	
+ CH	Ch+ DVBT	+ CH	Ch +
CH −	Ch- DVBT	CH −	Ch -
	Pause DVBT		Pause
1	1 DVBT	1	1
2	2 DVBT	2	2
3	3 DVBT	3	3
4	4 DVBT	4	4
5	5 DVBT	5	5
6	6 DVBT	6	6
7	7 DVBT	7	7
8	8 DVBT	8	8
9	9 DVBT	9	9
0	0 DVBT	0	0
	Power VCR	SHIFT +	Shi f t + Power
AV	Av VCR	TIMER AV	AV
	<< VCR		<<
	St op VCR		St op

Original		Substituto	
	>> VCR		>>
	Play VCR	PLAY MODE	Play
	Rec VCR	REC MODE	Rec
	Pause VCR	SHIFT +	Shift + Pause
GUIDE	Guide VCR	SHIFT + GUIDE	Shift + Guide
MENU	Menu VCR	SHIFT + TOP MENU MENU	Shift + Menu
	Up VCR	SHIFT +	Shift + Up
	Down VCR	SHIFT +	Shift + Down
	Left VCR	SHIFT +	Shift + Left
	Right VCR	SHIFT +	Shift + Right
OK	Ok VCR	SHIFT + OK	Shift + Ok
INFO	Info VCR	SHIFT + DISPLAY INFO	Shift + Info
EXIT	Exit VCR	CLEAR EXIT	Exit
	Red VCR	SHIFT + A	Shift + Red
	Green VCR	SHIFT + B	Shift + Green
	Yellow VCR	SHIFT + C	Shift + Yellow
	Blue VCR	SHIFT + D	Shift + Blue

Original		Substituto	
P-P	Back VCR	SHIFT + RETURN BACK	Shift + Back
+ CH	Ch+ VCR	SHIFT + + CH	Shift + Ch +
CH −	Ch- VCR	SHIFT + CH −	Shift + Ch -
1	1 VCR	SHIFT + 1	Shift + 1
2	2 VCR	SHIFT + 2	Shift + 2
3	3 VCR	SHIFT + 3	Shift + 3
4	4 VCR	SHIFT + 4	Shift + 4
5	5 VCR	SHIFT + 5	Shift + 5
6	6 VCR	SHIFT + 6	Shift + 6
7	7 VCR	SHIFT + 7	Shift + 7
8	8 VCR	SHIFT + 8	Shift + 8
9	9 VCR	SHIFT + 9	Shift + 9
0	0 VCR	SHIFT + 0	Shift + 0
* TXT	Text VCR	REPEAT TEXT	Text
# HELP	#Help VCR	FAV PRE-CH	Pre Ch