Original		Substituto	
DVD POWER	DVD Power	Power	Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
OPEN/CLOSE	Open / Close	CLEAR EXIT	Exit
SET UP	Setup	SETTINGS OPT	Options
ZOOM	Zoom	ZOOM	Eject
3D SOUND	3D Sound	ECO 3D	3D
BOOKMARK	Bookmark	FAV PRE-CH	Pre Ch
VOLUME CON.	Volume Con.	-/-- GUIDE	Guide

Original		Substituto	
<<	<<	<<	<<
>>	>>	>>	>>
Stop	Stop	Stop	Stop
Play / Pause	Play / Pause	PLAY MODE	Play
Play / Pause	Play / Pause	II	Pause
I <<	I <<	I <<	I <<
>>I	>>I	>>I	>>I
Return	Return	RETURN BACK	Back
STEP	Step	SHIFT + II	Shift + Pause
CLEAR	Clear	SHIFT + CLEAR EXIT	Shift + Exit
TOP MENU	Top Menu	SHIFT + TOP MENU MENU	Shift + Menu
TOP MENU	Top Menu	E-MANUAL D.MENU	D. Menu
DISPLAY	Display	DISPLAY INFO	Info
MENU	Menu	TOP MENU MENU	Menu
	Up		Up
	Left		Left
ENTER	Enter	OK	Ok

Original	Substituto
Right	Right
Down	Down
Audio	SOUND DUAL — Dual
Sub Title	AD SUBT — Subt
Angle	PICTURE FORMAT — Format
Repeat	REPEAT TEXT — Text
Repeat A-B	SHIFT + REPEAT TEXT — Shift + Text

Original	Substituto