Mandis shop

AA5900607A

Original		Substituto	
	Power		Power
SOURCE	Source	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
TTX/MIX	TTX/MIX	GOTO TEXT	Text / Goto
PRE-CH	PRE-CH	RETURN BACK	Back / Return
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
CH LIST	CH List	LIST SMART	Smart / List
+	Vol +	+ VOL	Vol +

Original		Substituto	
	Vol -	VOL −	Vol -
P	PR+	+ CH PAGE	CH+ / Page+
P	PR-	CH PAGE −	CH- / Page-
MEDIA.P	Media. P	MEDIA DISPLAY	Display / Media
MENU	Menu	HOME MENU	Menu / Home
HDMI	HDMI	SHIFT + HDMI - SAT 0	Shift + 0
TOOLS	Tools	OPT-TOOLS SETUP	Setup / OPT /
INFO	Info	ANGLE INFO	Info / Angle
RETURN	Return	SHIFT + RETURN BACK	Shift + Back / Return
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
▲	Up	▲	Up
▼	Down	▼	Down
◀	Left	◀	Left
▶	Right	▶	Right
	Enter	OK	OK
A	Red/A	NETFLIX SEARCH	Red / Netflix / Search
B	Green/B	APP REPEAT	Green / APP / Repeat

Original	Substituto	Original	Substituto
C Yellow/ C	YouTube REPEAT A-B Yellow / YouTube / Repeat		
D Blue/ D	Prime Video RANDOM Blue / Prime Video / Random		
PMODE P. Mode	FORMAT PICTURE Picture / Format		
P.SIZE P. Size	SIZE ZOOM Zoom / Size		
SRS SRS	TITLE SOUND Sound / Title		
■ Stop	HOLD ■ Stop / Hold		
◀◀ <<	TUNE- ◀◀ << / Tune-		
▶ Play	SLOW ▶ Play / Slow		
❚❚ Pause	STEP-FREEZE ❚❚ Pause / Step / Freeze		
▶▶ >>	TUNE+ ▶▶ >> / Tune+		