Original		Substituto	
I/⏻	Power	⏻	Power
SOCIAL VIEW	Social View	APP MEDIA	Media
Input		TIMER AV	AV
DIGITAL/ ANALOG	Digital / Analog	ZOOM ⏏	Eject
EXIT	Exit	CLEAR EXIT	Exit
FOOTBALL	Football	DISC NAV LIST	List
3D	3D	ECO 3D	3D
1 ./	1	1	1
2abc	2	2	2
3def	3	3	3
4 ghi	4	4	4
5 jkl	5	5	5
6mno	6	6	6
7pqrs	7	7	7
8 tuv	8	8	8
9 wxyz	9	9	9
0 ␣	0	0	0

Original		Substituto	
RADIO TV	TV/Radio	SEARCH TV/R	TV/R
≡	[≡]	REPEAT TEXT	Text
Red		A	Red
Green		B	Green
Yellow		C	Yellow
Blue		D	Blue
RELATED SEARCH TrackID	X/Related Search/Track ID	SHIFT +	SEARCH TV/R Shift + TV/R
SYNC MENU	Sync Menu	TOP MENU MENU	Menu
i-MANUAL ?	?/i-Manual	E-MANUAL D.MENU	D. Menu
DISCOVER	Discover	PROG SLEEP	Sleep
[i+]/[?]		DISPLAY INFO	Info
RETURN	Return/Back	RETURN BACK	Back
OPTIONS	Options	SETTINGS OPT	Options
HOME	Home	HOME SMART	Smart
GUIDE	Guide	-/-- GUIDE	Guide
	Up	▲	Up
	Down	▼	Down

Original	Substituto	Original	Substituto
Right	Right	>>I	>>I
Left	Left	Rec	Rec
OK	Ok	Stop	Stop
Vol +	Vol +	Tv Pause	Shift + Pause
Vol -	Vol -		
Mute	Mute		
Recall	Pre Ch		
Prog+	Ch +		
Prog-	Ch -		
Audio	Dual		
[. . .]	Subt		
[+]	Format		
<<	<<		
Play	Play		
>>	>>		
I <<	I <<		
Pause	Pause		