Original	Substituto	Original	Substituto
Mute	Mute / Dimmer	Exit / Back	Exit / Cancel / Clear
Power	Power	Up	Up
1	1	Left	Left
2	2	OK	OK
3	3	Right	Right
4	4	Down	Down
5	5	PR+	CH+ / Page+
6	6	Vol -	Vol -
7	7	Vol +	Vol +
8	8	PR-	CH- / Page-
9	9	[++]	Smart / List
S	Setup / OPT /	→I [/] I←	Display / Media
0	0	[i +]	Info / Angle
Source	AV / Input / RDS	Text	Text / Goto
Menu/ Menu	Menu / Home	I I >/ [▼]	Shift + >> /
Guide	Guide / EPG / -/--	Play/ O) I / I I	Play / Slow
Tv/ Fav/ Radio	TV/ Radio / Program	<</ [=o]	<< / Tune-

Original		Substituto		Original	Substituto
SUBTITLE	>>/ Subtitle	TUNE+	>> / Tune+		
	Open/close/[≡?]	SURROUND	Eject / Surround		
	Stop/[≡+]	HOLD	Stop / Hold		
	I<</[≡↕]	PRESET-	I<< / Preset-		
	>>I/[≡x]/[O]	PRESET+	>>I / Preset+		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		

Original		Substituto	
	Mute	DIMMER MUTE	Mute / Dimmer
	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
DVD MENU / MENU	_Menu/DVD	HOME MENU	Menu / Home
BACK / EXIT	_ Exit/Back	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	_ Up		Up
	Left		Left
OK	OK	OK	OK

Original		Substituto	
	Right		Right
	Down		Down
	Vol -	VOL −	Vol -
	Vol +	+ VOL	Vol +
II/III▶	▮▮/▮▮▶ / [▾]	STEP-FREEZE II	Pause / Step / Freeze
CD I/II ▶	▶ / I/II	SHIFT + SLOW ▶	Shift + Play /
CD I/II ▶	▶ / I/II	SLOW ▶	Play / Slow
◀◀	◀◀ / [≡◀]	TUNE- ◀◀	<< / Tune-
◀◀	◀◀ / [≡◀]	SHIFT + TUNE- ◀◀	Shift + << /
SUBTITLE ▶▶	▶▶ / Subtitle	SHIFT + TUNE+ ▶▶	Shift + >> /
SUBTITLE ▶▶	▶▶ / Subtitle	TUNE+ ▶▶	>> / Tune+
▲	▲	SURROUND ⏏	Eject / Surround
■	■ / [≡□]	HOLD ■	Stop / Hold
▮◀◀	▮◀◀ / [≡↕]	PRESET- ▮◀◀	I<< / Preset-
▮◀◀	▮◀◀ / [≡↕]	SHIFT + PRESET- ▮◀◀	Shift + I<< / Preset-
▶▶▮	▶▶▮ / [◷][≡X]	SHIFT + PRESET+ ▶▶▮	Shift + >>I / Preset+
▶▶▮	▶▶▮ / [◷][≡X]	PRESET+ ▶▶▮	>>I / Preset+

Original	Substituto	Original	Substituto
Mute	Mute / Dimmer	❚❚/❚❚▶ / [▾]	Pause / Step / Freeze
Power	Power	▶ / I/II	Shift + Play /
1	1	▶ / I/II	Play / Slow
2	2	◀◀ / [≡◕]	<< / Tune-
3	3	◀◀ / [≡◕]	Shift + << /
4	4	▶▶ / Subtitle	Shift + >> /
5	5	▶▶ / Subtitle	>> / Tune+
6	6	▲	Eject / Surround
– 7	7	■ / [≡▯]	Stop / Hold
– 8	8	▮◀◀ / [≡↕]	Shift + I<< / Preset-
– 9	9	▮◀◀ / [≡↕]	I<< / Preset-
0	0	▶▶▮ / [◷][≡X]	Shift + >>I / Preset+
Source	AV / Input / RDS	▶▶▮ / [◷][≡X]	>>I / Preset+
P+	CH+ / Page+		
Vol -	Vol -		
Vol +	Vol +		
P-	CH- / Page-		