Mandis shop

Yamaha FSR86

| Original | | Substituto | |
|---|---|---|---|
| | Power | | Power |
| TV | TV | A | Red |
| HDMI | HDMI | B | Green |
| ANALOG | Analog | C | Yellow |
| BLUETOOTH | Bluetooth | D | Blue |
| NET | Net | APP MEDIA | Media |
| 1 | Net Radio 1 | 1 | 1 |
| NET RADIO 2 | Net Radio 2 | 2 | 2 |
| 3 | Net Radio 3 | 3 | 3 |
| MOVIE | Movie | 7 | 7 |
| MUSIC | Music | 8 | 8 |
| SPORTS | Sports | 9 | 9 |
| GAME | Game | 0 | 0 |
| TV PROGRAM | Tv Program | SEARCH TV/R | TV/R |
| STEREO | Stereo | SOUND DUAL | Dual |
| CH LEVEL | CH Level | HOME SMART | Smart |
| CLEAR VOICE | Clear Voice | CLEAR EXIT | Exit |

| Original | | Substituto | |
|---|---|---|---|
| INFO | Info | DISPLAY INFO | Info |
| SETUP | Setup | SETTINGS OPT | Options |
| RETURN | Return | RETURN BACK | Back |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| ENTER | Enter | OK | Ok |
| + SUBWOOFER | Subwoofer+ | + CH | Ch + |
| SUBWOOFER − | Subwoofer- | CH − | Ch - |
| + VOLUME | Vol + | + VOL | Vol + |
| VOLUME − | Vol - | VOL − | Vol - |
| MUTE | Mute | MUTE | Mute |
| L | Position L | REPEAT TEXT | Text |
| C POSITION | Position C | ZOOM ⏏ | Eject |
| R | Position R | TIMER AV | AV |
| | | | |