Mandis shop

Yamaha RAX12

Original	Substituto
Standby/On	Power
Vol +	Vol +
Vol -	Vol -
Sleep	Sleep
AUX	6
Tape 1	4
Tape 2	5
Dir A Tape	Guide
Dir B Tape	Pre Ch
Rec/Pause Tape	Up
Play Tape	Ok
Stop Tape	Down
>> Tape	Right
<< Tape	Left
A/B Tape	0
Tuner	3
A/BC/D/E Tuner	Back

Original	Substituto
Preset + Tuner	Ch +
Preset - Tuner	Ch -
CD	2
Phono	1
Play CD Phono	Play
Pause/Stop CD	Stop
Disc CD Phono	Media
>> CD Phono	>>
<< CD Phono	<<
>>I CD Phono	>>I
I << CD Phono	I <<

https://ordenador/p/Yamaha/1342-627-mando-substituto-para-Yamaha-RAX12-WB72180.htm