Mandis shop

Yamaha RAS13

Original		Substituto	
AMP	Power AMP		Power
OPEN/CLOSE	Open/Close	ZOOM	Eject
CD	Power CD	SHIFT +	Shift + Power
PURE DIRECT	Pure Direct	GUIDE	Guide
COAXIAL	Coaxial	4	4
OPTICAL	Optical	5	5
LINE 1	Line 1	1	1
LINE 2	Line 2	2	2
LINE 3	Line 3	3	3
TUNER	Tuner	6	6
PHONO	Phono	7	7
CD	CD	8	8
BAND	Band		Up
TUNING	<< Tuning	CH −	Ch -
TUNING	Tuning >>	+ CH	Ch +
MEMORY	Memory	OK	Ok
PRESET	< Preset		Left

Original		Substituto	
PRESET	Preset >		Right
	<<		<<
DISC SKIP	Disc Skip	HOME SMART	Smart
	>>		>>
	Pause		Pause
	Stop		Stop
	Play	PLAY MODE	Play
	>>I		>>I
	I <<		I <<
VOLUME	Vol +	+ VOL	Vol +
VOLUME	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute