Original		Substituto	
POWER	Power		Power
AUX	Input AUX	SHIFT + AUX-HDD 7	Shift + 7
PHONO	Input PHONO	SHIFT + HDMI-SAT 0	Shift + 0
TAPE 1	Input TAPE1	SHIFT + TAPE 5	Shift + 5
TUNER	Input TUNER	SHIFT + TUNER 6	Shift + 6
CD	Input CD	SHIFT + CD-STB 3	Shift + 3
VCR 2	Input VCR 2	SHIFT + BLUETOOTH 9	Shift + 9
VCR 1	Input VCR 1	SHIFT + VIDEO 4	Shift + 4
TV/DBS	Input TV / DBS	SHIFT + TV 1	Shift + 1
LD	Input LD	SHIFT + DVD 2	Shift + 2
TAPE 2 MON	Input TAPE 2 MON	SHIFT + USB 8	Shift + 8
CHAP	I<< / Chapter-	PRESET-	I<< / Preset-
APTER +	>>I / Chapter+	PRESET+	>>I / Preset+
PAUSE/STOP	Pause / Stop	STEP-FREEZE	Pause / Step / Freeze
PAUSE/STOP	Pause / Stop	HOLD	Stop / Hold
PLAY	Play	SLOW	Play / Slow
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Original		Substituto	
SEAR	<< Search	TUNE-	<< / Tune-
ARCH	Search >>	TUNE+	>> / Tune+
DIR A	Dat-Tape-Vcr Dir	TITLE SOUND	Sound / Title
PLAY	Dat-Tape-Vcr Pla	SHIFT + SLOW	Shift + Play /
DIR B	Dat-Tape-Vcr Dir	LANG I/II AUDIO	Audio / Lang I/II
DECK A/B	Dat-Tape-Vcr Deck A/B	EQ SUBTITLE	Subtitle / EQ
	Dat-Tape-Vcr	SHIFT + TUNE-	Shift + << /
STOP	Dat-Tape-Vcr Stop	SHIFT + HOLD	Shift + Stop /
	Dat-Tape-Vcr	SHIFT + TUNE+	Shift + >> /
TEST	Test	GOTO TEXT	Text / Goto
A/B/C/D/E	Tuner-Vcr-Tv A/B/C/D/E/F	LIST SMART	Smart / List
PRESE	Tuner-Vcr-Tv Preset/CH-	+ CH PAGE	CH+ / Page+
SET/CH +	Tuner-Vcr-Tv Preset/CH+	CH PAGE −	CH- / Page-
FRONT LEVEL	Front Level +	SHIFT + + VOL	Shift + Vol +
HALL 1 1	Hall 1	TV 1	1
HALL 2 2	Hall 2	DVD 2	2
HALL 3 3	Hall 3	CD-STB 3	3

Original	Substituto
Church	4
Front Level -	Shift + Vol -
Rock Concert	5
Jazz Club	6
Concert Video	7
Disco	8
Center Level +	Shift + Smart / List
TV Theater	9
Movie Theater	Guide / EPG / -/--
Stadium	0
12 / DD Pro Logi	Fav / Marker / PC
Center Level -	Shift + Display / Media
On Screen	Info / Angle
Parameter Up	Up
Set Menu Up	Shift + Up
Master Volume	Vol +
Rear Level +	Shift + CH+ / Page+

Original	Substituto
Parameter -	Left
Set Menu -	Shift + Left
Parameter +	Right
Set Menu +	Shift + Right
Master Volume	Vol -
Rear Level -	Shift + CH- /
Effect On/Off	OK
Parameter	Down
Set Menu Down	Shift + Down
Muting	Mute / Dimmer

Original		Substituto	
POWER	Power		Power
AUX	Input AUX	SHIFT + AUX-HDD 7	Shift + 7
PHONO	Input PHONO	SHIFT + HDMI-SAT 0	Shift + 0
TAPE 1	Input TAPE1	SHIFT + TAPE 5	Shift + 5
TUNER	Input TUNER	SHIFT + TUNER 6	Shift + 6
CD	Input CD	SHIFT + CD-STB 3	Shift + 3
VCR 2	Input VCR 2	SHIFT + BLUETOOTH 9	Shift + 9
VCR 1	Input VCR 1	SHIFT + VIDEO 4	Shift + 4
TV/DBS	Input TV / DBS	SHIFT + TV 1	Shift + 1
LD	Input LD	SHIFT + DVD 2	Shift + 2
TAPE 2 MON	Input TAPE 2 MON	SHIFT + USB 8	Shift + 8
CHAP	I<< / Chapter-	PRESET-	I<< / Preset-
APTER +	>>I / Chapter+	PRESET+	>>I / Preset+
PAUSE/STOP	Pause / Stop	STEP-FREEZE	Pause / Step / Freeze
PAUSE/STOP	Pause / Stop	HOLD	Stop / Hold
PLAY	Play	SLOW	Play / Slow
DISPLAY	Display	MEDIA DISPLAY	Display / Media

Original		Substituto	
STIL	I< Still	SHIFT + PRESET-	Shift + I<< / Preset-
TILL	Still >I	SHIFT + PRESET+	Shift + >>I / Preset+
SEAF	<< Search	TUNE-	<< / Tune-
ARCH	Search >>	TUNE+	>> / Tune+
DIR A	Tape-Vcr Dir A	TITLE SOUND	Sound / Title
PLAY	Tape-Vcr Play	SHIFT + SLOW	Shift + Play /
DIR B	Tape-Vcr Dir B	LANG I/II AUDIO	Audio / Lang I/II
DECK A/B	Tape-Vcr Deck	EQ SUBTITLE	Subtitle / EQ
	Tape-Vcr <<	SHIFT + TUNE-	Shift + << /
STOP	Tape-Vcr Stop	SHIFT + HOLD	Shift + Stop /
	Tape-Vcr >>	SHIFT + TUNE+	Shift + >> /
TEST	Test	GOTO TEXT	Text / Goto
A/B/C/D/E	Tuner-Vcr-Tv A/B/C/D/E/F	LIST SMART	Smart / List
PRESE	Tuner-Vcr-Tv Preset/CH-	CH PAGE	CH- / Page-
SET/CH	Tuner-Vcr-Tv Preset/CH+	CH PAGE	CH+ / Page+
FRONT LEVEL	Front Level +	SHIFT + VOL	Shift + Vol +
HALL 1	Hall 1	TV 1	1

Original	Substituto
Hall 2	2
Hall 3	3
Church	4
Front Level -	SHIFT + VOL − (Shift + Vol -)
Rock Concert	5
Jazz Club	6
Concert Video	7
Disco	8
Center Level +	SHIFT + SMART (Shift + Smart / List)
TV Theater	9
Movie Theater	GUIDE EPG (Guide / EPG / -/--)
Stadium	0
12 / DD Pro Logi	FAV MARKER (Fav / Marker / PC)
Center Level -	SHIFT + DISPLAY (Shift + Display / Media)
On Screen	INFO (Info / Angle)
Parameter Up	Up
Set Menu Up	SHIFT + ▲ (Shift + Up)

Original	Substituto
Master Volume	VOL + (Vol +)
Rear Level +	SHIFT + CH+ (Shift + CH+ /)
Parameter -	Left
Set Menu -	SHIFT + ◀ (Shift + Left)
Parameter +	Right
Set Menu +	SHIFT + ▶ (Shift + Right)
Master Volume	VOL − (Vol -)
Rear Level -	SHIFT + CH− (Shift + CH- /)
Effect On/Off	OK
Parameter	Down
Set Menu Down	SHIFT + ▼ (Shift + Down)
Muting	DIMMER MUTE (Mute / Dimmer)