Original	Substituto	Original	Substituto
Dimmer	SHIFT + DIMMER MUTE — Shift + Mute / Dimmer	Memory	REC MODE — Rec / Rec Mode
Sleep	TIMER SLEEP — Sleep / Timer	< Preset	CH PAGE – — CH- / Page-
Power	Power	< Preset	SHIFT + PRESET- — Shift + I<< / Preset-
Speakers A	TITLE SOUND — Sound / Title	Preset >	CH PAGE + — CH+ / Page+
Speakers B	LANG I/II AUDIO — Audio / Lang I/II	Preset >	SHIFT + PRESET+ — Shift + >>I / Preset+
Optical	TV 1 — 1	Clear	CLEAR EXIT CANCEL — Exit / Cancel / Clear
Coaxial	DVD 2 — 2	Mode	FORMAT PICTURE — Picture / Format
CD	CD-STB 3 — 3	Display	MEDIA DISPLAY — Display / Media
Line 1	VIDEO 4 — 4	Up	Up
Line 2	TAPE 5 — 5	Left	Left
Phono	AUX-HDD 7 — 7	Enter	OK — OK
Tuner	TUNER 6 — 6	Right	Right
Net	USB 8 — 8	Down	Down
Bluetooth	BLUETOOTH 9 — 9	Home	HOME MENU — Menu / Home
Band	LIST SMART — Smart / List	Return	RETURN BACK — Back / Return
<< Tuning	SHIFT + TUNE- — Shift + << /	Setup	OPT-TOOLS SETUP — Setup / OPT /
Tuning >>	SHIFT + TUNE+ — Shift + >> / Tune+	Volume+	VOL + — Vol +

Original	Substituto	Original	Substituto
OPTION Option	SHIFT + OPT-TOOLS SETUP Shift + Setup / OPT / Tools		
NOW PLAYING Now Playing	-/-- GUIDE EPG Guide / EPG / -/--		
VOLUME Volume-	VOL – Vol -		
MUTE Mute	DIMMER MUTE Mute / Dimmer		
REPEAT Repeat	APP REPEAT Green / APP / Repeat		
▷/DD Play	SLOW ▶ Play / Slow		
▷/DD Pause	STEP-FREEZE ⏸ Pause / Step / Freeze		
SHUFFLE Shuffle	Prime Video RANDOM Blue / Prime Video / Random		
⏮/◁◁ I <<</ <<	TUNE- ◀◀ << / Tune-		
⏮/◁◁ I <<</ <<	PRESET- ⏮ I << / Preset-		
▭ Stop	HOLD ■ Stop / Hold		
▷▷/▷▷I >>/ >>I	TUNE+ ▶▶ >> / Tune+		
▷▷/▷▷I >>/ >>I	PRESET+ ▶▶I >>I / Preset+		