| Original | | Substituto | |
|---|---|---|---|
| | Eject | SURROUND | Eject / Surround |
| | Power | | Power |
| PROGRAM | Red/Program | NETFLIX SEARCH | Red / Netflix / Search |
| PROGRAM | Red/Program | PROGRAM TV/RADIO | TV/Radio / |
| MARKER | Green/Marker | APP REPEAT | Green / APP / Repeat |
| DIGEST | Yellow/Digest | YouTube REPEAT A-B | Yellow / YouTube / Repeat |
| ZOOM | Blue/Zoom | Prime Video RANDOM | Blue / Prime Video / Random |
| ZOOM | Blue/Zoom | SIZE ZOOM | Zoom / Size |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| STATUS | Status | FORMAT PICTURE | Picture / Format |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| SUBTITLE | Subtitle | EQ SUBTITLE | Subtitle / EQ |
| 7 | 7 | AUX-HDD 7 | 7 |

| Original | | Substituto | |
|---|---|---|---|
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| ANGLE | Angle | ANGLE INFO | Info / Angle |
| CLEAR | Clear | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| 0 | 0 | HDMI-SAT 0 | 0 |
| SEARCH | Search | SHIFT + NETFLIX SEARCH | Shift + Red / Netflix / |
| AUDIO | Audio | LANG I/II AUDIO | Audio / Lang I/II |
| PIP | PIP | TIMER SLEEP | Sleep / Timer |
| SETUP | Setup | OPT-TOOLS SETUP | Setup / OPT / |
| REPEAT | Repeat | SHIFT + APP REPEAT | Shift + Green / APP / |
| 2ND AUDIO | 2nd Audio | TITLE SOUND | Sound / Title |
| HOME | Home | LIST SMART | Smart / List |
| HOME | Home | SHIFT + HOME MENU | Shift + Menu / |
| A/B | A/B | SHIFT + YouTube REPEAT A-B | Shift + Yellow / YouTube / |
| TOP MENU | Top Menu | TOP MENU D.MENU | D.Menu / Top |
| POP-UP/MENU | Pop-Up/Menu | HOME MENU | Menu / Home |
| | Up | | Up |

| Original | Substituto | Original | Substituto |
|---|---|---|---|
| Left | Left | | |
| Enter | OK | | |
| Right | Right | | |
| Return | Back / Return | | |
| Down | Down | | |
| On Screen | Display / Media | | |
| Stop | Stop / Hold | | |
| Pause | Pause / Step / Freeze | | |
| Play | Play / Slow | | |
| ◁ / ◁I | SHIFT + I<< / Preset- | | |
| I> / II> | SHIFT + >I / Preset+ | | |
| << | << / Tune- | | |
| >> | >> / Tune+ | | |
| <◁ | CH- / Page- | | |
| I>> | CH+ / Page+ | | |
| I<< | I<< / Preset- | | |
| >>I | >>I / Preset+ | | |

https://ordenar.com/p/Yamaha-BDP118-Mando-de-Substituto-para-Yamaha-BDP118-Mando-Substituto-para-Yamaha-BDP118-Mando-Substituto-para-Yamaha-BDP118-Mando