



ORIGINAL	REPLACEMENT
POWER	POWER
MUTE	MUTE
MENU	MENU
1/2/3/4/5	1/2/3/4/5
6/7/8/9/0	6/7/8/9/0
INPUT NEXT	AV
DOLBY / DTS	-/--
ON SCREEN	
STEREO	
ANGLE	
SUBTITLE	
VOLUME+	VOL+
VOLUME-	VOL-
SKIP NEXT	P+
SKIP PREV.	P-
UP	UP
DOWN	DOWN
LEFT	LEFT
RIGHT	RIGHT
ENTER	OK
RETURN	BACK
SLEEP	SLEEP
STATUS	INFO
TEST	EPG
MATRIX 6.1	FAV

ORIGINAL	REPLACEMENT
PAUSE	
STOP	
REW	GREEN
PLAY	YELLOW
FWD	BLUE
AUDIO	SHIFT+MUTE
SET MENU	SHIFT+MENU
AMP.	SHIFT+1
DVD / CD	SHIFT+2
TUNER	SHIFT+3
VCR	SHIFT+4
VIDEO	SHIFT+5
SURR.-	SHIFT+ VOL-
SURR.+	SHIFT+ VOL+
CH -/+	SHIFT+ P-/+
CENTER-	SHIFT+DOWN
CENTER+	SHIFT+UP
SW.-	SHIFT+LEFT
SW.+	SHIFT+RIGHT
SELECT	SHIFT+OK
NIGHT	SHIFT+SLEEP
CINEMA DSP – MOVIE	SHIFT+RED
CINEMA DSP – MUSIC	SHIFT+GREEN
CINEMA DSP – SPORTS	SHIFT+YELLOW
CINEMA DSP – GAME	SHIFT+BLUE