

NOKIA
TV
RCN641-TV

Mandis Shop S.L.
Sant Cugat del Vallès (Barcelona)
info@mandis.es

TV=TV; VCR=DVD SAT=SAT



Layout Keys	Direct	Shift	Layout Keys	Direct	Shift
POWER	Power		V	Down	
MUTE	Mute		EXIT		
1	1		BACK		
2	2		VOL+		
3	3		VOL-		
4	4		INFO	i	
5	5		HAW(PSI)	Recall	
6	6		CH-		
7	7		CH+		
8	8		TEXT	Text	
9	9		< ?	Sound	
0	0		...		
VOID	Ideal		TWRADIO	TV	
MENU	Menu		CFI+		
>PLAY			SOURCE		
PAUSE			V-FORMAT	Size	
(STOP	Stop		WIDE	Vision	
RECORD					
<<					
>>					
<<					
>>					
RED	Red				
GREEN	Green				
YELLOW	Yellow				
BLUE	Blue				
MEDIA					
EPG(GUIDE)					
OK	OK				
^	Up				
<	Left				
>	Right				