

SONY
SMART TV
BN59-01259B-1

Mandis Shop S.L.
Sant Cugat del Vallès (Barcelona)
info@mandis.es



Layout Keys	Direct	Shift	Layout Keys	Direct	Shift
POWER	Power		V	Down	
MUTE			EXIT		
1	123		BACK	Back	
2			VOL+	Vol	
3	Extra		VOL-		
4			INFO		
5			FAV(LIST)		
6			CH+	CH	
7			CH-		
8			TEXT		
9			< ?		
0			...		
VOD			TV/RADIO		
MENU	Home		OPT+		
>PLAY	Play		SOURCE		
PAUSE	Pause		V-FORMAT		
[]STOP			WIDE		
oRECORD					
<<					
>>					
<<					
>>					
RED					
GREEN					
YELLOW					
BLUE					
MEDIA					
EPG(GUIDE)					
OK	OK				
^	p				
<	Left				
>	Right				