

YAMAHA
RECEPTOR
RAS2

Mandis Shop S.L.
Sant Cugat del Vallès (Barcelona)
info@mandis.es



Layout Keys	Direct	Shift	Layout Keys	Direct	Shift
POWER	Power		V	Down	
MUTE	Mute		EXIT		
1	<< Tuning		BACK	Disc Skip	
2	Tuning >>		VOL+	Vol+	
3	Band		VOL-	Vol-	
4	Treble-		INFO	Info	
5	Treble+		FAV(LIST)	Open/Close	
6			CH+	Preset >	
7	Bass-		CH-	< Preset	
8	Bass+		TEXT	Balance L	
9			< ?		
0	Memory		...		
VOD	Sleep		TV/RADIO	Tuner	
MENU	Menu		OPT+	Pure Direct	
>PLAY	Play		SOURCE	Balance R	
PAUSE	Pause		V-FORMAT		
[J]STOP	Stop		WIDE		
oRECORD					
<<	<<				
>>	>>				
<<	<<				
>>	>>				
RED	Line 1				
GREEN	Line 2				
YELLOW	CD				
BLUE	Phono				
MEDIA	Dimmer				
EPG(GUIDE)	A/B/C/D/E				
OK	Enter				
^	Up				
<	Left				
>	Right				