

































































































Original	Substituto	Original	Substituto
 Power	 Power	 P+	 CH +
 Source	 SRC	 P-	 CH -
 1	 1	 CH List	 TV/R
 2	 2	 Content	 Shift + VOD
 3	 3	 Menu	 MENU
 4	 4	 Guide	 -/-- / EPG
 5	 5	 Tools	 OPT+
 6	 6	 Info	 INFO
 7	 7	 Return	 BACK
 8	 8	 Exit	 EXIT
 9	 9	 Up	 UP
 0	 0	 Down	 DOWN
 TTX/MIX	 TEXT	 Right	 RIGHT
 PRE-CH	 P/C / FAV	 Left	 LEFT
 Vol+	 VOL +	 Enter	 OK
 Vol-	 VOL -	 Red	 Red (A)
 Mute	 MUTE	 Green	 Green (B)





Original	Substituto	Original	Substituto
 Yellow	 Yellow (C)		
 Blue	 Blue (D)		
 Media. P	 MEDIA		
 Internet/@TV	 VOD		
 Dual I-II	 Audio		
 AD	 WIDE		
 P.Size	 V-FOR		
 Subt.	 Subt.		
 <<	 Rewind		
 Pause	 Pause		
 >>	 Fast Forward		
 Rec	 Rec		
 Play	 Play		
 Stop	 Stop		

