






























































Original	Substituto	Original	Substituto
	Power		Power
	OK		OK
	Up		UP
	Down		DOWN
	Right		RIGHT
	Left		LEFT
	Return		BACK
	Play		Play
	Pause		Pause
	Extra		MEDIA
	Mute		MUTE
	Vol+		VOL +
	Vol-		VOL -
	Guide		-/-- / EPG
	CH+		CH +
	CH-		CH -
	Home		VOD

Original	Substituto	Original	Substituto
	Source		SRC
	TTX/MIX		TEXT
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	PRE-CH		P/C / FAV
	Exit		EXIT
	Info		INFO
	Menu		MENU
	Red		Red (A)





Original	Substituto	Original	Substituto
Green	 B Green (B)		
Yellow	 C Yellow (C)		
Blue	 D Blue (D)		
123	 TV/R TV/R		
Tools	 OPT+ OPT+		
Stop	 Stop Stop		
Rec	 Rec Rec		
<</ <<	 Rewind Rewind		
>>/>>	 Fast Forward Fast Forward		
CH List	 WIDE WIDE		
AD/Subt.	 Subt. Subt.		
E-Manual	 Audio Audio		

