







































































Original	Substituto	Original	Substituto
 Mute	 Mute / Dimmer	 P+	 CH+ / Page+
 Power	 Power	 Vol-	 Vol-
 1	 1	 EPG/?/A-B	 Shift + Yellow / YouTube /
 2	 2	 EPG/?/A-B	 Guide / EPG / -/--
 3	 3	 P-	 CH- / Page-
 4	 4	 Up	 Up
 5	 5	 Left	 Left
 6	 6	 OK	 OK
 7	 7	 Right	 Right
 8	 8	 Down	 Down
 9	 9	 Q/Double	 Shift + Red / Netflix /
 16:9	 Picture / Format	 M	 Menu / Home
 0/FAV	 Fav / Marker / PC	 ←	 Back / Return
 0/FAV	 0	 i	 Info / Angle
 [O]/Repeat	 Shift + Green / APP /	 Red	 Red / Netflix / Search
 Vol+	 Vol+	 Play/Pause	 Play / Slow
 Input	 AV / Input / RDS	 Green	 Green / APP / Repeat

Original	Substituto	Original	Substituto
 Mute	 Mute / Dimmer	 P+	 CH+ / Page+
 Power	 Power	 Vol-	 Vol-
 1	 1	 EPG/?/A-B	 Shift + Yellow / YouTube /
 2	 2	 EPG/?/A-B	 Guide / EPG / -/--
 3	 3	 P-	 CH- / Page-
 4	 4	 Up	 Up
 5	 5	 Left	 Left
 6	 6	 OK	 OK
 7	 7	 Right	 Right
 8	 8	 Down	 Down
 9	 9	 Q/Double	 Shift + Red / Netflix /
 16:9	 Picture / Format	 M	 Menu / Home
 0/FAV	 Fav / Marker / PC	 ←	 Back / Return
 0/FAV	 0	 i	 Info / Angle
 [O]/Repeat	 Shift + Green / APP /	 Red	 Red / Netflix / Search
 Vol+	 Vol+	 Play/Pause	 Play / Slow
 Input	 AV / Input / RDS	 Green	 Green / APP / Repeat





Original	Substituto
	<< / Tune-
	Yellow / YouTube / Repeat
	Stop / Hold
	Blue / Prime Video / Random
	>> / Tune+
	I<< / Preset-
	Text / Goto
	>>I / Preset+
	Subtitle / EQ
	Audio / Lang I/II

Original	Substituto

