







































































Original	Substituto	Original	Substituto
 Power	 Power	 World	 Media
 Source	 AV	 Vol+	 Vol +
 1	 1	 Vol-	 Vol -
 2	 2	 PR+	 Ch +
 3	 3	 PR-	 Ch -
 4	 4	 OK	 Ok
 5	 5	 Up	 Up
 6	 6	 Down	 Down
 7	 7	 Right	 Right
 8	 8	 Left	 Left
 9	 9	 Back	 Back
 0	 0	 Exit	 Exit
 TV	 TV/R	 i	 Info
 Mute	 Mute	 Guide	 Guide
 Recall	 Pre Ch	 /Music/Photo/Movi	 Dual
 Menu	 Menu	 [=]/Text	 Text
 Q.Menu	 D. Menu	 */o	 Format





Original	Substituto	Original	Substituto
	* / o ..		3D
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	Lang		List
	[≡] ..		Subt
	[-o-]		Shift + 3D
	Rec		Rec
	Play		Play
	Pause		Pause
	Stop		Stop
	>>		>>
	<<		<<

