


























































































	Original	Substituto		Original	Substituto
	Power		Power		Vol +
	Mute		Mute		Vol -
	1		1		Ok
	2		2		Up
	3		3		Down
	4		4		Right
	5		5		Left
	6		6		Menu
	7		7		Exit
	8		8		Sleep
	9		9		Aspect
	0		0		Rec
	Recall		Pre Ch		Red/DVD-Setup
	PR.List		List		Green/Repeat
	Source		AV		Yellow/Languag
	CH+		Ch +		Blue/DVD-Menu
	CH-		Ch -		Title/PC Auto





Original	Substituto
 Zoom/Tv/Radio	 TV/R
 I/II/Audio	 Dual
 Subtitle	 Subt
 Info/Display	 Info
 Step/Freeze	 Back
 Prog/Index	 Media
 A-B/Reveal	 D. Menu
 Text/Eject	 Text
 Play/Size	 Play
 Pause/Subpage	 Pause
 Stop/Hold	 Stop
 I<<	 I<<
 >>I	 >>I
 <<	 <<
 >>	 >>
 S.Mode	 Shift + Dual
 Pic.Mode	 Shift + Format

Original	Substituto
 Rec List	 Shift + Subt

