




| Original | Substituto | Original | Substituto |
|---|------------|---|-----------------------------|
|  | Power |  | Power |
|  | Screen |  | Picture / Format |
|  | Lang |  | Audio / Lang I/II |
|  | Subtitle |  | Subtitle / EQ |
|  | www |  | Smart / List |
|  | Red/▲ |  | Red / Netflix / Search |
|  | Red/▲ |  | Shift + CH+ / |
|  | Green/▼ |  | Green / APP / Repeat |
|  | Green/▼ |  | Shift + CH- / |
|  | Yellow |  | Yellow / YouTube / Repeat |
|  | Blue |  | Blue / Prime Video / Random |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | [≡]/Text |  | Text / Goto |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | Recall |  | Back / Return |
|  | Up |  | Up |
|  | Menu |  | Menu / Home |
|  | Left |  | Left |
|  | Right |  | Right |
|  | Return |  | Shift + Back / Return |
|  | Down |  | Down |
|  | OK |  | OK |
|  | Source |  | AV / Input / RDS |
|  | FAV |  | Fav / Marker / PC |
|  | Presets |  | Setup / OPT / |
|  | Sleep |  | Sleep / Timer |





| Original | | Substituto | | Original | | Substituto | |
|----------|------|------------|--------------------|----------|--|------------|--|
| V+ | Vol+ | | Vol+ | | | | |
| P+ | P+ | | CH+ / Page+ | | | | |
| | Info | | Info / Angle | | | | |
| | Mute | | Mute / Dimmer | | | | |
| | EPG | | Guide / EPG / -/-- | | | | |
| V- | Vol- | | Vol- | | | | |
| P- | P- | | CH- / Page- | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

