



































































































Original	Substituto	Original	Substituto
	Power		Power
	[i+]		Info / Angle
	Sleep		Sleep / Timer
	AV Mode		Setup / OPT /
	DTV Menu		D.Menu / Top
	▼/O/I/II/I+II		Audio / Lang I/II
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	Vol+		Vol+
	4		4
	5		5
	6		6
	Vol-		Vol-
	7		7
	8		8
	9		9
	P+		CH+ / Page+
	Recall		Back / Return
	0		0
	Source		AV / Input / RDS
	P-		CH- / Page-
	DTV		Smart / List
	[<>]		Picture / Format
	PC		Fav / Marker / PC
	Radio		TV/Radio /
	[> <]		Pause / Step / Freeze
	Menu		Menu / Home
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	End		Exit / Cancel / Clear





Original		Substituto		Original		Substituto	
	Down		Down				
	Return		Shift + Back / Return				
	Red		Red / Netflix / Search				
	Green		Green / APP / Repeat				
	Yellow		Yellow / YouTube / Repeat				
	Blue		Blue / Prime Video / Random				
	EPG		Guide / EPG / -/--				
	[≡]		Text / Goto				
	[≡?]		Play / Slow				
	[...]		Subtitle / EQ				
	ESG		Display / Media				
	[≡+]		Stop / Hold				
	[≡o]		Rec / Rec Mode				
	[≡♦]		Zoom / Size				

