







































































Original	Substituto	Original	Substituto
	Power		Power
	Source		AV
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	TTX/MIX		Text
	PRE-CH		Pre Ch
	Vol+		Vol +
	Vol-		Vol -
	PR+		Ch +

Original	Substituto	Original	Substituto
	PR-		Ch -
	Mute		Mute
	Ch.List		List
	Media.P		Media
	Menu		Menu
	Guide		Guide
	Tools		Options
	Info		Info
	Return		Back
	Exit		Exit
	Enter		Ok
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Red		Red
	Green		Green





Original		Substituto		Original	Substituto
	Yellow		Yellow		
	Blue		Blue		
	P.Mode	+	Shift + Format		
	S.Mode	+	Shift + Dual		
	Dual I/II		Dual		
	AD	+	Shift + Subt		
	P.Size		Format		
	Subt.		Subt		
	<<		<<		
	Pause		Pause		
	>>		>>		
	Rec		Rec		
	Play		Play		
	Stop		Stop		

