



| Original | Substituto | Original | Substituto |
|----------|------------|----------|------------------|
| | Mute | | Mute / Dimmer |
| | Power | | Power |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | Swap | | Setup / OPT / |
| | 0 | | 0 |
| | AV | | AV / Input / RDS |
| | [] | | Shift + 1 |
| | ♪ | | Sound / Title |
| | [<>] | | Picture / Format |

| Original | Substituto | Original | Substituto |
|----------|------------|----------|-----------------------------|
| | [i] | | Info / Angle |
| | Up | | Up |
| | Left | | Left |
| | OK | | OK |
| | Right | | Right |
| | Down | | Down |
| | Red | | Red / Netflix / Search |
| | Green | | Green / APP / Repeat |
| | Yellow | | Yellow / YouTube / Repeat |
| | Blue | | Blue / Prime Video / Random |
| | Vol+ | | Vol+ |
| | Text | | Text / Goto |
| | Menu | | Menu / Home |
| | CH+ | | CH+ / Page+ |
| | Vol- | | Vol- |
| | Back | | Back / Return |
| | Tv/Exit | | TV/Radio / |



