






















































| Original   | Substituto  | Original   | Substituto  |
|--|---|--|---|
|  Power          |  Power             |  Left         |  Left                        |
|  1              |  1                 |  OK           |  OK                          |
|  2              |  2                 |  Right        |  Right                       |
|  3              |  3                 |  I<<          |  I<< / Preset-               |
|  4              |  4                 |  Down         |  Down                        |
|  5              |  5                 |  >>I          |  >>I / Preset+               |
|  6              |  6                 |  Stop         |  Stop / Hold                 |
|  7              |  7                 |  Play         |  Play / Slow                 |
|  8              |  8                 |  Pause        |  Pause / Step / Freeze       |
|  9             |  9                |  Subtitle    |  Subtitle / EQ              |
|  Title/Return |  Back / Return   |  Angle      |  Info / Angle              |
|  Title/Return |  Sound / Title   |  Zoom       |  Zoom / Size               |
|  0            |  0               |  Audio      |  Audio / Lang I/II         |
|  Display      |  Display / Media |  Repeat     |  Green / APP / Repeat      |
|  Disc Menu    |  D.Menu / Top    |  Repeat A-B |  Yellow / YouTube / Repeat |
|  Up           |  Up              |  Preview    |  Smart / List              |
|  System Menu  |  Menu / Home     |  Mute       |  Mute / Dimmer             |

| Original   | Substituto  | Original   | Substituto  |
|--|---|--|---|
|  Left         |  Left                        |  Left         |  Left                        |
|  OK           |  OK                          |  OK           |  OK                          |
|  Right        |  Right                       |  Right        |  Right                       |
|  I<<          |  I<< / Preset-               |  I<<          |  I<< / Preset-               |
|  Down         |  Down                        |  Down         |  Down                        |
|  >>I          |  >>I / Preset+               |  >>I          |  >>I / Preset+               |
|  Stop         |  Stop / Hold                 |  Stop         |  Stop / Hold                 |
|  Play         |  Play / Slow                 |  Play         |  Play / Slow                 |
|  Pause        |  Pause / Step / Freeze       |  Pause        |  Pause / Step / Freeze       |
|  Subtitle    |  Subtitle / EQ              |  Subtitle    |  Subtitle / EQ              |
|  Angle      |  Info / Angle              |  Angle      |  Info / Angle              |
|  Zoom       |  Zoom / Size               |  Zoom       |  Zoom / Size               |
|  Audio      |  Audio / Lang I/II         |  Audio      |  Audio / Lang I/II         |
|  Repeat     |  Green / APP / Repeat      |  Repeat     |  Green / APP / Repeat      |
|  Repeat A-B |  Yellow / YouTube / Repeat |  Repeat A-B |  Yellow / YouTube / Repeat |
|  Preview    |  Smart / List              |  Preview    |  Smart / List              |
|  Mute       |  Mute / Dimmer             |  Mute       |  Mute / Dimmer             |

