



Original	Substituto	Original	Substituto
	Power		Power
	Mute		Mute / Dimmer
	Tv Input		AV / Input / RDS
	Q.View		Menu / Home
	Vol+		Vol+
	PR+		CH+ / Page+
	Vol-		Vol-
	PR-		CH- / Page-
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0

