





Original	Substituto
	Mute
	Power
	1
	2
	3
	4
	5
	6
	7
	8
	9
	APP
	APP
	0
	Back
	L-
	L+

Original	Substituto
	Menu
	Up
	Exit
	Left
	OK
	Right
	CH+
	Down
	Vol+
	CH-
	Vol-
	Info
	List
	EPG
	Red
	Green
	Yellow





Original		Substituto	
	Blue		Blue / Prime Video / Random
	Audio		Audio / Lang I/II
	Subt		Subtitle / EQ
	Text		Text / Goto
	Tv/Rad.		TV/Radio /
	OPT		Setup / OPT /
	Still		Pause / Step / Freeze
	Tv/AV		AV / Input / RDS

Original	Substituto

