



Original	Substituto	Original	Substituto
POWER	Power	POWER	Power
MUTE	Mute	MUTE	Mute
FREEZE	Freeze	II	Pause
SLEEP	Sleep	PROG SLEEP	Sleep
PIP SOURCE	PIP Source	ZOOM	Eject
MAIN	Main	E-MANUAL D.MENU	D. Menu
SWAP	Swap	FAV PRE-CH	Pre Ch
POSITION	Position	SETTINGS OPT	Options
SIZE	Size	PICTURE FORMAT	Format
PIP	PIP	HOME SMART	Smart
(≡)(-)	(≡)(-)	REPEAT TEXT	Text
(≡)(o)	(≡)(o)	SEARCH TV/R	TV/R
(≡)(i)	(≡)(i)	- / - GUIDE	Guide
(≡)(♦)	(≡)(♦)	APP MEDIA	Media
(≡)(▲)	(≡)(▲)	>>I	>>I
(≡)(▼)	(≡)(▼)	I<<	I<<
(+)	(+)	CLEAR EXIT	Exit

Original	Substituto	Original	Substituto
(≡)(x)	(≡)(x)	DISC NAV LIST	List
(≡)(?)	(≡)(?)	AD SUBT	Subt
Red	Red	A	Red
Green	Green	B	Green
Yellow	Yellow	C	Yellow
Blue	Blue	D	Blue
Picture	Picture	SHIFT +  PICTURE FORMAT	Shift + Format
Aspect	Aspect	ECO 3D	3D
Up	Up		Up
Down	Down		Down
Right	Right		Right
Left	Left		Left
Audio	Audio	SOUND DUAL	Dual
Vol+	Vol+	+ VOL	Vol +
Source	Source	TIMER AV	AV
Vol-	Vol-	VOL -	Vol -
Menu	Menu	TOP MENU MENU	Menu





Original	Substituto	Original	Substituto
1	1		
2	2		
3	3		
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
0	0		
i	i		
R	R		

