



Original	Substituto	Original	Substituto
	Power		Power
	Last		Pre Ch
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	TV/R		TV/R
	Audio		Dual
	Info		Info
	Mode		D. Menu
	Favor		Options
	Menu		Menu
	Sub-T		Subt
	Exit		Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	CH+		Ch +
	CH-		Ch -
	Vol+		Vol +
	Vol-		Vol -
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue





Original	Substituto	Original	Substituto
EPG	EPG	GUIDE	Guide
TEXT	Text	REPEAT TEXT	Text





Original	Substituto	Original	Substituto
Power		Power	
Last		Pre Ch	
Mute		Mute	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
0		0	
TV/R		TV/R	
Audio		Dual	
Info		Info	
Mode		D. Menu	

Original	Substituto	Original	Substituto
Favor		Options	
Menu		Menu	
Sub-T		Subt	
Exit		Exit	
Up		Up	
Down		Down	
Right		Right	
Left		Left	
OK		Ok	
CH+		Ch +	
CH-		Ch -	
Vol+		Vol +	
Vol-		Vol -	
Red		Red	
Green		Green	
Yellow		Yellow	
Blue		Blue	





Original	Substituto	Original	Substituto
EPG	Guide		
Text	Text		





Original	Substituto	Original	Substituto
Power		Power	
Last		Pre Ch	
Mute		Mute	
1		1	
2		2	
3		3	
4		4	
5		5	
6		6	
7		7	
8		8	
9		9	
0		0	
TV/R		TV/R	
Audio		Dual	
Info		Info	
Mode		D. Menu	

Original	Substituto	Original	Substituto
Favor		Options	
Menu		Menu	
Sub-T		Subt	
Exit		Exit	
Up		Up	
Down		Down	
Right		Right	
Left		Left	
OK		Ok	
CH+		Ch +	
CH-		Ch -	
Vol+		Vol +	
Vol-		Vol -	
Red		Red	
Green		Green	
Yellow		Yellow	
Blue		Blue	





Original	Substituto	Original	Substituto
EPG	GUIDE		Guide
Text	REPEAT TEXT		Text

