



| Original  | Substituto | Original  | Substituto    |
|---|------------|---|---------------|
|      | Power      |      | Power         |
|      | Tv/R       |      | TV/R          |
|      | Input      |      | AV            |
|      | Mute       |      | Mute          |
|      | 1          |      | 1             |
|      | 2          |      | 2             |
|      | 3          |      | 3             |
|      | 4          |      | 4             |
|      | 5          |      | 5             |
|      | 6          |      | 6             |
|    | 7          |    | 7             |
|    | 8          |    | 8             |
|    | 9          |    | 9             |
|    | 0          |    | 0             |
|    | -/--       |    | Shift + Guide |
|    | Exit       |    | Exit          |
|    | Menu       |    | Menu          |
|    | P+         |    | Ch +          |
|    | P-         |    | Ch -          |
|    | Vol+       |    | Vol +         |
|    | Vol-       |    | Vol -         |
|    | Up         |    | Up            |
|    | Down       |    | Down          |
|    | Right      |    | Right         |
|    | Left       |    | Left          |
|    | OK         |    | Ok            |
|    | i          |    | Info          |
|  | Audio      |  | Dual          |
|  | Sub        |  | Subt          |
|  | Guide      |  | Guide         |
|  | TXT        |  | Text          |
|  | Back       |  | Back          |
|  | Pause      |  | Pause         |
|  | F1         |  | List          |







| Original  | Substituto | Original  | Substituto    |
|---|------------|---|---------------|
|      | Power      |      | Power         |
|      | TV/R       |      | TV/R          |
|      | Source     |      | AV            |
|      | Mute       |      | Mute          |
|      | 1          |      | 1             |
|      | 2          |      | 2             |
|      | 3          |      | 3             |
|      | 4          |      | 4             |
|      | 5          |      | 5             |
|      | 6          |      | 6             |
|    | 7          |    | 7             |
|    | 8          |    | 8             |
|    | 9          |    | 9             |
|    | 0          |    | 0             |
|    | -/--       |    | Shift + Guide |
|    | Menu       |    | Menu          |
|    | Exit       |    | Exit          |
|    | P+         |    | Ch +          |
|    | P-         |    | Ch -          |
|    | V+         |    | Vol +         |
|    | V-         |    | Vol -         |
|    | Up         |    | Up            |
|    | Down       |    | Down          |
|    | Right      |    | Right         |
|    | Left       |    | Left          |
|    | OK         |    | Ok            |
|    | i          |    | Info          |
|  | Audio      |  | Dual          |
|  | Sub        |  | Subt          |
|  | Guide      |  | Guide         |
|  | TXT        |  | Text          |
|  | ↔          |  | Back          |
|  | Pause      |  | Pause         |
|  | F1         |  | Options       |



