







































































Original	Substituto	Original	Substituto
 Power	 Power	 Mute / [Q]	 Mute / Dimmer
 1	 1	 i	 Info / Angle
 2	 2	 Z / Back	 Back / Return
 3	 3	 CH+	 CH+ / Page+
 4	 4	 Up	 Up
 5	 5	 Vol-	 Vol-
 6	 6	 Left	 Left
 7	 7	 OK	 OK
 8	 8	 Right	 Right
 9	 9	 Vol+	 Vol+
 0	 0	 Down	 Down
 AV	 AV / Input / RDS	 CH-	 CH- / Page-
 ? / Audio	 Audio / Lang I/II	 TXT/Menu	 Menu / Home
 PIP / Repeat	 Fav / Marker / PC	 TXT/Menu	 Text / Goto
 PIP / Repeat	 Shift + Green / APP /	 TV-G/Top Menu	 D.Menu / Top
 [<>] / [...]	 Shift + Picture / Format	 TV-G/Top Menu	 Guide / EPG / -/-
 [<>] / [...]	 Subtitle / EQ	 Red / Eye	 Red / Netflix / Search







































































	Original	Substituto	Original	Substituto
	Rec	Rec / Rec Mode		
	Green / Timer	Sleep / Timer		
	Play	Play / Slow		
	Green / Timer	Green / APP / Repeat		
	Yellow	Yellow / YouTube / Repeat		
	Pause	Pause / Step / Freeze		
	Blue / Audio	Shift + Audio / Lang I/II		
	Stop	Stop / Hold		
	Blue / Audio	Blue / Prime Video / Random		
	Scan	Smart / List		
	I<	I<< / Preset-		
	PAT	Eject / Surround		
	>I	>>I / Preset+		
	S	Sound / Title		
	<<	<<< / Tune-		
	P	Picture / Format		
	>>	>>> / Tune+		






Original	Substituto	Original	Substituto
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	AV		AV / Input / RDS
	i		Info / Angle
	Exit		Exit / Cancel / Clear
	Up		Up
	CH+		CH+ / Page+
	Left		Left

Original	Substituto	Original	Substituto
	Vol-		Vol-
	OK		OK
	Right		Right
	Vol+		Vol+
	Down		Down
	CH-		CH- / Page-
	Menu		Menu / Home
	Top Menu		D.Menu / Top
	Red		Red / Netflix / Search
	Rec		Rec / Rec Mode
	Green		Green / APP / Repeat
	Play		Play / Slow
	Yellow		Yellow / YouTube / Repeat
	Pause		Pause / Step / Freeze
	Blue		Blue / Prime Video / Random
	Stop		Stop / Hold
	I<		I<< / Preset-





Original	Substituto	Original	Substituto
 >	 >> / Preset+		
 <<	 << / Tune-		
 >>	 >> / Tune+		

